

TOSHIBA

Touch Screen Controller

Model name:

BMS-CT1280E





BMS-CT1280E-TR

Contents

Safety Precautions	3
1 Product Overview	5
2 System Configuration	36
3 Initial Settings	38
4 Troubleshooting	52
5 Service Parts	55
Installation Manual	
Network Configuration Guide	
Owner's Manual	

Safety Precautions

- This section explains safety precautions you must follow in order to prevent harm to the user and other persons and damage to property.
- "Display Description" explains the classification of the degree of harm or damage that may occur if the unit is handled incorrectly, while "Symbol Description" indicates the meanings of symbols.



Display Description	Symbol Description
 WARNING Indicates "Content that is expected to result in death or serious injury (*1) to the user in the case of incorrect handling".	 ○ indicates prohibited actions. Specifically prohibited contents are indicated with a picture and/or text in or near the symbol.
 CAUTION Indicates "Content that is expected to result in minor injury (*2) to the user or damage to property (*3) in the case of incorrect handling".	 ● indicates instructions which must be followed. The actual contents of the instructions are indicated with a picture and/or text in or near the symbol.

* 1: Serious injury refers to lasting after effects such as blindness, injury, burns (high temperature / low temperature), electric shock, bone fracture, or poisoning, etc. and injuries that require hospitalization/long-term outpatient treatment.






* 2: Minor injury refers to injuries, burns, or electric shocks, etc. that do not require hospitalization or long-term outpatient treatment.

* 3: Damage to property refers to extended damage related to houses, household goods, livestock, or pets, etc.

DANGER

- 
Turning off the circuit-breaker
 - **Set the circuit-breaker to "OFF" before starting work**
Failing to do so may result in a high-voltage electric shock, leading to death or injury.
- 
Prohibited
 - **Do not turn on the circuit-breaker when the cover is removed**
Doing so may result in a high-voltage electric shock leading to death or injury.

WARNING

- 
Check earth connection
 - **Check that the earth wire (*) is connected to the unit earth terminal before beginning troubleshooting and repair work**
If the earth wire is not connected, there is the risk of electric shock in the event of an electric leakage occurring.
- 
Modification prohibited
 - **Do not modify the product**
Also, do not disassemble or modify the parts.
Doing so may cause fire, electric shock, or injury.
- 
Children must be kept away
 - **Only qualified engineers should be allowed on a troubleshooting or repair work site. Children and all other third parties must be kept away**
There is a risk of injury from tools or disassembled parts.
Inform the customer that children and other third parties must be kept away from the work site.
- 
Insulation
 - **After connecting a crimp terminal to a cut lead wire, place the closed-end facing up and clean it**
If connections are not properly processed, electrical leakage, ignition or other accident could occur on the customer's premises.
- 
Wiring Precautions During Assembly
 - **After repairs are complete, be sure to reassemble the disassembled parts and connect and route the wires to restore the equipment to its original state. Make sure internal wires are not trapped in the cabinets, panels, or other parts**
An assembly or wire connection problem may result in a short circuit, ignition or other accident on the customer's premises.



Insulation check

- **After the work is completed, be sure to test between the live and dead metal parts (earth terminal) with an insulation resistance tester (500 V) to confirm that the insulation resistance is 2 MΩ or higher**

A low insulation resistance value may result in a short circuit, electric shock or other accident on the customer's premises.



Risk of electric shock

- **If you have to inspect a circuit that is energized, for example, take precautions such as wearing rubber gloves to avoid direct contact with a live part**

Touching a live part may result in an electric shock.



Check after repair

- **Check that there are no abnormalities after completing the repair work**

Failure to perform this check may result in fire, electric shock, or injury.

Turn off the earth leakage breaker before performing an inspection.

- **After completing the repair work, perform a test run and check that there are no abnormalities such as smoke or unusual noise**

Failure to perform this check may result in fire or electric shock.

Perform a test run after installing the front panel and cabinets.



Repair and reinstallation work

- **Installation and reinstallation work should be performed by your vendor or a qualified electrician**

Attempting to carry out installation work on your own, and doing so incorrectly, may result in electric shock or fire.

1 Product Overview

1-1. Function list

Specifications

Detailed specifications

Power supply	220-240 V AC 50/60 Hz
Operating temperature/ humidity range	0°C to 40°C, 10% to 90% RH (no dew condensation)
Dimensions (mm)	H136×W205×D10(+80) (Embedded dimensions shown in parenthesis)
Mass	1.34 kg (Touch Screen Controller) 0.45 kg (power adapter)
LCD	Type 7 TFT liquid crystal, 800×480, 167,000 colours (Luminance 800 cd/m ² , contrast ratio 600:1)
Touch Screen	Projection-capacitive type
Communication ports	· RS-485 port ×1 (for connecting four digital I/O interfaces and four watt hour meter interfaces) · LAN port ×1 (for connecting PC)
USB port	USB memory stick connection port ×2
External contact input	8 inputs
External contact output	4 inputs
Included PC software (Requires a separate PC (*1))	· Remote Control Software · Report Creation Software · Section Changeover Software · Data Analyzer

*1 Conditions for PC connection (operating environment)
 OS: Windows 8.1 or Windows 10
 LAN port: 10BASE-T or 100BASE-TX wired LAN port
 Other: mouse/keyboard, printer (if printing is required)

Function list

Key Features		
Control	ON/OFF	
	Setting mode	
	Set temp.	
	Fan speed settings	
	Swing ON	
	Local remote controller operation lock/unlock	
	Ventilation → ON/OFF	
	Ventilation → Mode	
	Ventilation → Fan speed	
	Soft Cooling	
	Energy saving ratio [%]	
	Eco Temperature Shift	
	Set temp. range limit	
	Filter Sign Reset	
	Monitoring	ON/OFF
Setting mode		
Set temp.		
Fan speed settings		
Swing ON		
Local remote controller operation lock/unlock		
Ventilation → ON/OFF		
Ventilation → Mode		
Ventilation → Fan speed		
Soft Cooling		
Energy saving ratio [%]		
Eco Temperature Shift		
Set temp. range limit		
Outdoor temp.		
Power Level		
Return Back		
Power peak cut		
FILTER Sign		
Schedule	Setting unit (Per unit)	
	Setting unit: Week Schedule (per day of the week)	
	Setting unit: Particular Timer setting (per date)	
	Setting time (00:00 to 23:59)	
	Setting content	ON/OFF
		Setting mode
		Set temp.
		Local remote controller operation lock/unlock
		Return Back
		Energy saving ratio [%]
Ventilation operation setting		
Vent. Mode		
Maximum number of schedules per day 64		


Key Features			
External input	Inputs	Main unit	8 inputs
		DIO interface	8 inputs x 4 units
	Functions	Power pulse measurement	
		Demand Interlocking	
		Fire Alarm Interlocking	
		Security Interlocking	
		Stop Interlocking	
		Operation Interlocking	
		For ON/OFF indication	
		For alarm indication	
External output	Outputs	Main unit	4 outputs
		DIO interface	4 outputs x 4 units
	Functions	Alarm Output Interlocking	
		Operation Output Interlocking	
		Controller Error Output Interlocking	
		For ON/OFF control	

1-2. Air conditioner control monitoring


This section explains the basic setting method for operation Start/Stop and air conditioning, the setting method for the operation schedule, and the confirmation method for the overall air conditioning system.

Start/Stop Operation


Overall air conditioning system operation method




1 Tap



2 Tap [2-(1)] or [2-(2)]




3 Check the contents of the message and tap [3-(1)]




4 When the screen on the left appears, check the contents of the message and tap [4-(1)] or [4-(2)] *

All air conditioners and ON/OFF unit start/stop operation.


* About confirmation pop-up selection




Group unit operation method




1 Scroll the home screen to display the group you want to change the settings for, then tap **>**



2 Tap **[2-(1)]** or **[2-(2)]**




3 Check the contents of the message and tap **[3-(1)]**




4 When the screen on the left appears, check the contents of the message and tap [4-(1)] or [4-(2)] *

All group air conditioners and ON/OFF equipment turn ON or OFF.


* About confirmation pop-up selection




Operation method in units of air conditioner or ON/OFF unit




1 Scroll the home screen and display the air conditioner or ON/OFF unit that you want to change the settings for



2 Drag or flick the  of the corresponding switch

Drag or flick to the right to start operation.
Drag or flick to the left to stop operation.




NOTE


You can also start/stop operation by tapping the power icon on the [CONTROL] tab on the individual control screen displayed by tapping the switch.

Change the Air Conditioning Settings (ON/OFF/Mode/Wind direction/Fan Speed/Set temp.)


Group unit operation method



1 Scroll the home screen to display the group you want to change the settings for, then tap >




2 Tap [2-(1)]
The batch settings screen is displayed.



3 Change settings

Example: When changing the operation status settings

3-1 Tap [3-(1)]
The operation status settings screen is displayed.






3-2 Set the check box of [3-(2)] to
You can now change the settings.

3-3 Select [3-(3)] or [3-(4)] and tap [3-(5)]
Return to the batch settings screen.


3-4 Change the other items with reference to steps 3-1 to 3-3
For the setting details, see the following table.

No.	Name	Functions
1	ON/OFF	Can be set to [ON/OFF].
2	Mode	Can be set to [Auto/Heat/Dry/Cool/Fan]. NOTE <ul style="list-style-type: none"> A bar is displayed at the bottom of the icon for the currently selected mode. Operation modes that cannot be set are not displayed.


No.	Name	Functions
3	Wind direction	<p>Tap ◀ ▶ to switch to the following.</p>  <p>• NOTE</p> <p>Depending on the connected model, items that cannot be set are not displayed.</p>
4	Fan Speed	<p>Tap ◀ ▶ to switch to the following.</p>  <p>• NOTE</p> <ul style="list-style-type: none"> For models with limited fan speed setting range, this is changed to the values that can be set for each model. Fan speeds that cannot be set are not displayed.
5	Set temp.	<p>Tap ▲ ▼ to change the set temperature.</p> <p>• NOTE</p> <ul style="list-style-type: none"> When set to a temperature outside the setting range limit of each operation mode, the temperature is changed to the upper or lower limit of the setting range. If there are Dual Set Point compatible models in the group, two tabs will be displayed. When you tap [3-(6)], one set temperature is displayed, and when you tap [3-(7)], two set temperatures are displayed. Tap ▲ ▼ to change the set temperature. 

• **NOTE**


- For models that do not have the function set, the setting change is ignored.
- For the setting of [Lock] [Unlock] of [3-(8)], see "Local Remote Controller Lock" (Owner's Manual P.40).
- For the [Option] settings of [3-(9)], see "Set Operation Details" (Owner's Manual P.42).



4 Confirm that the changed item is checked, and tap [4-(1)]




5 Check the contents of the message and tap [5-(1)]



6 When the screen on the left appears, check the contents of the message and tap [6-(1)] or [6-(2)] *
The settings of the entire group are changed.


*** About confirmation pop-up selection**




Air conditioner unit operation method

NOTE


To change the settings, it is necessary to set to the operation status. (P.9)




1 Scroll the home screen, display the air conditioner you want to change the settings for, then tap the switch



2 Change settings

No.	Name	Functions						
1	Mode	<p>Can be set to [Auto/Heat/Dry/Cool/Fan].</p> <p>NOTE</p> <ul style="list-style-type: none"> A bar is displayed at the bottom of the icon for the currently selected mode. Operation modes that cannot be set are not displayed. 						
2	Wind direction	<p>Tap to switch to the following.</p>  <table border="1"> <thead> <tr> <th>Operation Mode</th> <th>Setting Range</th> </tr> </thead> <tbody> <tr> <td>Auto (Cool)/Cool/Dry</td> <td>Swing ON→Swing OFF→F1→F2→F3→Swing ON (Return to the beginning)</td> </tr> <tr> <td>Auto (Heat)/Heat/Fan</td> <td>Swing ON→Swing OFF→F1→F2→F3→F4→F5→Swing ON (Return to the beginning)</td> </tr> </tbody> </table> <p>NOTE</p> <ul style="list-style-type: none"> The setting range varies depending on the operation mode. There is a function to set only [Swing ON]. 	Operation Mode	Setting Range	Auto (Cool)/Cool/Dry	Swing ON→Swing OFF→F1→F2→F3→Swing ON (Return to the beginning)	Auto (Heat)/Heat/Fan	Swing ON→Swing OFF→F1→F2→F3→F4→F5→Swing ON (Return to the beginning)
Operation Mode	Setting Range							
Auto (Cool)/Cool/Dry	Swing ON→Swing OFF→F1→F2→F3→Swing ON (Return to the beginning)							
Auto (Heat)/Heat/Fan	Swing ON→Swing OFF→F1→F2→F3→F4→F5→Swing ON (Return to the beginning)							

No.	Name	Functions
3	Fan Speed	<p>Tap to switch to the following.</p>  <p>• NOTE</p> <p>Fan speeds that cannot be set are not displayed.</p>
4	Set temp.	<p>Tap ▲ ▼ to change the set temperature.</p> <p>• NOTE</p> <ul style="list-style-type: none"> • If the operation mode is FAN, the temperature cannot be set. • "Control temp." shows the indoor temperature detected by the outdoor unit. *Depending on conditions such as the installation site of the indoor unit, it may differ from actual room temperature. • An icon and a message are displayed here during frost protection preparation, heat preparation or other operations.

• **NOTE**

- For the setting of [(1)], see "Local Remote Controller Lock" (Owner's Manual P.40).
- For the setting of [(2)], see "Set Operation Details" (Owner's Manual P.42).
- If there is no corresponding function, that item is not displayed.

Example of a model without a flap



Since you cannot set the air direction, it does not change even if you tap it.

Example of a model where only a certain fan speed can be set



Since you cannot change the fan speed, it does not change even if you tap it.

1-3. Scheduled functions

Set the Operation Schedule

You can configure the air conditioners or the ON/OFF unit with a “Week Schedule”, through which settings such as operation start/stop are changed depending on the specified time for any day from Sunday to Saturday, or a “Particular Timer setting”, through which settings are changed for special days such as national holidays or special holidays. The operation schedule is set on the [SCHEDULE] tab of the group screen or individual control screen.

NOTE

If a day is set in both the Week Schedule and the Particular Timer setting, the Particular Timer setting applies and the Week Schedule is disabled for that day.

Screen description


This section explains how to view the [SCHEDULE] tab when setting the operation schedule.

NOTE

Refer to the description of the [CONTROL] tab for the display items that are not explained. (Owner's Manual P.16,18)

Group screen


The schedule set for the air conditioners or ON/OFF unit in the group is displayed in list format in time units.



No.	Functions
1	You can switch the display in day-of-week units.
2	Displays the setting screen of Particular Timer setting.
3	Displays the setting screen of Week Schedule.
4	The schedule settings content (ON/OFF, Mode, Temp., Lock, more) is displayed.
5	The times when the schedule is executed and the air conditioners and ON/OFF unit for which the schedule is executed are displayed.

Individual control screen

The schedule set for the air conditioner or ON/OFF unit being displayed is displayed on a 24-hour time scale.




No.	Functions
1	You can switch the display in day-of-week units.
2	Displays the setting screen of Particular Timer setting.
3	Displays the setting screen of Week Schedule.
4	🕒 is displayed at the times when the schedule is set. When operation start/stop is set, [ON] or [OFF] is displayed below 🕒. When setting change is set, ⚙️ is displayed below 🕒. Also, the currently displayed schedule is displayed in blue.
5	The schedule settings content (ON/OFF, Mode, Temp., Lock, more) is displayed.
6	You can switch the display to the previous or next schedule.
7	The times when the schedule will be executed are displayed.
8	The schedule setting number is displayed.

Create a new Week Schedule


In a Week Schedule, you can set:

- Start time
- Day(s) of the week
- Air conditioner(s) or ON/OFF unit
- ON/OFF


Schedule settings can be applied from either the group screen or the individual control screen. In the following procedure, the individual control screen is used to explain.




1 Tap [SCHEDULE] on the group screen or individual control screen




2 Tap [2-(1)]




3 Tap +



4 Tap or flick to set the start time and tap [4-(1)]




5 Select the day of the week to execute and tap [5-(1)]




6 Select the air conditioner(s) or ON/OFF unit for setting the schedule and tap [6-(1)]

You cannot select a model that has already been scheduled at the same time.



7 Tap the check box of [7-(1)] and set it to , then select [7-(2)] or [7-(3)] and tap [7-(4)]

You can only set [ON/OFF] here.



A schedule has been registered.


NOTE

- When setting details such as operation mode or set temperature, etc. as a schedule, refer to "Change the details of the Week Schedule" (P.21).
- When deleting a registered schedule, refer to "Delete the operation schedule" (P.27).


Create a new Particular Timer setting

In a Particular Timer setting, you can register special days, such as national holidays and special holidays, to configure a special schedule that differs from the Week Schedule.


Schedules can be configured from the group screen or the individual control screen. The following procedure is explained using the individual control screen.




1 Tap [SCHEDULE] on the group screen or the individual control screen



2 Tap [2-(1)]



3 Tap >




4 Tap [4-(1)] and set the schedule name


A keyboard is displayed. Enter the name and then tap [4-(2)].



5 Tap + to go to step 6

NOTE

- Tap [Shift] to toggle between upper case letters and lower case letters, and numbers and symbols.
- Tap  to delete one character.




6 Tap or flick to set the start date, and then tap [6-(1)]



7 Tap the check box of [7-(1)] and set it to , then select [7-(2)] or [7-(3)] and tap [7-(4)]

You can only set [ON/OFF] here.



The schedule is registered.

NOTE

- When setting details such as the mode or the set temperature to a schedule, refer to "Change the details of the Particular Timer setting" (P.23).
- When deleting a registered schedule, refer to "Delete the operation schedule" (P.27).


Change the Operation Schedule

The operating schedule settings can be changed from the [Menu] button, the group screen, or the individual control screen. There are two types of operating schedules: Week Schedule and Particular Timer setting. The following procedure is explained using the individual control screen.


NOTE

If a day is set in both the Week Schedule and the Particular Timer setting, the Particular Timer setting applies and the Week Schedule is disabled for that day.


Change the details of the Week Schedule




1 Tap [1-(1)] on the group screen or the individual control screen



2 Tap [2-(1)]



3 Tap > of the schedule you want to modify




4 Modify the target air conditioner(s) or ON/OFF unit, then tap [4-(1)]




- 5** Scroll the screen and tap the value of the item you want to set. After changing the setting, tap [OK]
See "Setting items list" (P.25) for the items that can be configured.


Change the details of the Particular Timer setting




1 Tap [1-(1)] on the group screen or the individual control screen




2 Tap [2-(1)]




3 Tap > of the schedule you want to modify




4 Tap [4-(1)] to switch to the Assign screen




5 Modify the target air conditioner(s) or ON/OFF unit, then tap [5-(1)]




6 Tap the date you want to configure, modify the settings, and then tap [6-(1)]



7 Tap > of the schedule you want to modify













8 Tap > of the time you want to modify



9 Scroll the screen and tap the value of the item you want to set. After changing the setting, tap [OK]
See "Setting items list" (P.25) for the items that can be configured.


Setting items list

Setting Items	Setting Procedure
<p>Time setting [Start date]</p> 	<p>Tap or flick to change the time.</p>
<p>Day of the week setting [week]</p> 	<p>Set the check box(es) of the day(s) of the week on which you want to execute the schedule to <input checked="" type="checkbox"/>.</p> <p>• NOTE</p> <p>The day of the [week] setting is not displayed in Particular Timer setting.</p>
<p>Operation setting [ON/OFF]</p> 	<p>To enable the setting, set the check box of [(1)] to <input checked="" type="checkbox"/> and select a value.</p>
<p>Operation mode setting [Mode]</p> 	<p>To enable the setting, set the check box of [(2)] to <input checked="" type="checkbox"/> and select a value.</p>
<p>Set temperature setting [Set temp.]</p> 	<p>To enable the setting, set the check box of [(3)] to <input checked="" type="checkbox"/>, tap ▲ ▼, then change the set temperature.</p>


Setting Items	Setting Procedure
<p>Return Back settings [Return Back]</p> 	<p>An energy saving function whereby if you temporarily change the set temperature to one which increases the load, you can automatically return to the energy saving set temperature after a certain time has elapsed. For example, if you set COOL to 28°C/30 minutes, then if the set temperature is set to below 28°C, the Unit will return to 28°C 30 minutes after the change.</p> <p>NOTE</p> <p>Displayed in the case of a compatible air conditioner.</p>
<p>Local operation prohibition setting [Lock setting of remote control]</p> 	<p>Tap the check box of the function whose setting you want to change to set it to <input checked="" type="checkbox"/>, then select [(1)] or [(2)].</p>
<p>Save operation setting [Energy saving ratio[%]]</p> 	<p>To enable the setting, set the check box of [(3)] to <input checked="" type="checkbox"/>. For details, see "Control air conditioner power (Energy saving ratio [%])" (Owner's Manual P.46).</p>
<p>Ventilation operation setting [Ventilation -> ON/OFF]</p> 	<p>You can turn ON/OFF the operation of the ventilator connected to the air to air heat exchanger(s) or air conditioner(s). To enable the setting, set the check box of [(4)] to <input checked="" type="checkbox"/> and apply the setting.</p>
<p>Vent. Mode [Ventilation -> Mode]</p> 	<p>You can set the ventilation mode of the ventilator connected to the air to air heat exchanger(s) or the air conditioner(s). To enable the setting, set the check box of [(5)] to <input checked="" type="checkbox"/> and apply the setting. For details, see "Set Ventilation Mode (Ventilation → Mode)" (Owner's Manual P.44).</p>

Delete the operation schedule

You can delete the schedule from either the group screen or the individual control screen. In the following procedure, the individual control screen is used.




1 Tap [1-(1)] on the group screen or individual control screen



2 Tap [2-(1)] to go to step 4


3 (In case of Particular Timer setting) tap [3-(1)]

Tap of the schedule you want to modify to go to step 4.




4 Tap

(Some displayed items differ between the Week Schedule screen and the Particular Timer setting screen, but the procedure shown below is the same.)



5 Set the check box of the schedule you want to delete to then tap [5-(1)]



1-4. External I/O

Number of points

The external input has the following number of input points.

Equipment	Input/Output	Number of points
Main unit	External input	8 points
	External output	4 points
DIO I/F 1	External input	8 points
	External output	4 points
DIO I/F 2	External input	8 points
	External output	4 points
DIO I/F 3	External input	8 points
	External output	4 points
DIO I/F 4	External input	8 points
	External output	4 points

* It is necessary to implement crossover wiring with RS-485 for DIO I/F and the main unit.

Functions

The following functions can be set for the main unit and DIO I/F 1 to 4, respectively.

Input/Output	I / O Function	Functions	Settings	
Input	Electric power	Count the power pulses. Measure a pulse waveform of 50 msec or more as one pulse.	• Pulse constant (kWh/pulse)	
	Control	Stop	When ON, stops the specified air conditioner.	• a contact (ON at signal input, OFF at release)/ b contact (OFF at signal input, ON at release)
		Run	When ON, runs the specified air conditioner.	• a contact (ON at signal input, OFF at release)/ b contact (OFF at signal input, ON at release)
		Lock	When ON, controls the specified air conditioner to the specified setting contents.	• a contact (ON at signal input, OFF at release)/ b contact (OFF at signal input, ON at release) • Pattern 0 (Stop at ON, do nothing at OFF)/ Pattern 1 (Stop at ON, "Run/Stop" at OFF switch prohibit release)/ Pattern 2 (Stop at ON + "Run/Stop" switching prohibited, "Run/Stop" at OFF switching prohibited release)/ Pattern 3 (Stop/Run)
		Fire alarm	At ON, turn OFF the specified air conditioner and set the local remote prohibited status, and at OFF, release the local remote control prohibited status.	• a contact (ON at signal input, OFF at release)/ b contact (OFF at signal input, ON at release)
		Demand	At ON, perform demand control on the specified air conditioner.	• a contact (ON at signal input, OFF at release)/ b contact (OFF at signal input, ON at release) • Indoor unit (Thermo OFF (no delay release)/ Thermo OFF (10 seconds delay)/ Thermo OFF (20 seconds delay)/ Thermo OFF (30 seconds delay)/ Thermo OFF (60 seconds delay)/ FAN/ Stop + local remote control operation prohibited/ FAN + local remote control mode change prohibited) • Outdoor unit (0%/60%/70%/80%)
Operation monitoring of external equipment	At ON, displays the associated external equipment as Operation status, and at OFF, displays it as Stop status.	• a contact (ON at signal input, OFF at release)/ b contact (OFF at signal input, ON at release)		

Input/Output	I / O Function		Functions	Settings
Input	Control	Alarm monitoring of external equipment	At ON, displays the associated external equipment as Alarm detected status, and at OFF, displays it as No alarm.	• a contact (ON at signal input, OFF at release)/ b contact (OFF at signal input, ON at release)
Output	Control	Air conditioner alarm output	One or more specified air conditioners turn ON when an alarm occurs and turn OFF when the alarm goes OFF.	• a contact (at ON, signal output, at OFF, output Stop) fixed
		Operation output	One or more specified air conditioners turn ON when operating, and turn OFF when all turn OFF.	• a contact (at ON, signal output, at OFF, output Stop) fixed
		System alarm output	With this system excluding air conditioners, it turns ON when an alarm occurs and turns OFF when the alarm goes OFF.	• a contact (at ON, signal output, at OFF, output Stop) fixed
		Refrigerant leakage output *During normal operation, do not set.	Turns ON when a refrigerant leakage signal is detected and turns OFF when the detection stops.	• a contact (at ON, signal output, at OFF, output Stop) fixed * During normal operation, do not set.
		Operation output to external equipment	Turns ON when the associated external equipment is operated and turns OFF when stopped.	• a contact (at ON, signal output, at OFF, output Stop) fixed

* Each function can be set in [Server/Interface] - [Interface Settings] in the setting file creation software.

1-5. Power distribution system

“Report Creation Software” is software that creates monthly reports based on the operation results of individual air conditioning units within the air conditioning control system. The software also includes electrical power distribution and charge calculation functions.

The electrical power distribution function distributes the amount of electricity used for each air conditioner, based on the power meter pulse-integrated value measured in the air conditioning control system.

The charge calculation function calculates the charge for each air conditioning unit based on the electric unit price and the amount of electricity distributed to each air conditioner.

Files can be saved in Excel[®], CSV and PDF formats.

CAUTION

- Using the accumulated power meter with pulse output, the system calculates the distribution of power accumulated by pulse conversion according to the load proportion estimated for each air-conditioner. The result is not calculated based on the Measurement Act and cannot be used officially.
 - Even if the operation hour is the same, the amount of power consumed varies depending on operating conditions such as the location of the air-conditioner, the set temperature, and the outdoor temperature.
 - The air-conditioner stays on for protection, even while stopped, and power is consumed. Therefore the system also calculates power consumed while the air-conditioner is not in use.
 - The system calculates the distribution of power according to the load proportion estimated for each air-conditioner. Therefore the result may differ from the actual amount of power consumed.
 - If a single power meter is installed in multiple air-conditioners, the total power is distributed. The result may differ when a power meter is installed in each air-conditioner.
 - The system calculates the pulse output using the accumulated power meter with pulse output. The result may differ from the actual amount of power consumed depending on the precision of the power meter. In particular, when the amount of electricity consumed in operation is low (when stopped, etc.), the result may differ from the actual amount of power consumed.
 - Please note that we bear no responsibility for any damage or problems that occur due to the system’s distribution calculation, data loss, etc.
 - The calculation result contains rounding errors.
 - The system only supports the distribution calculation of power consumed by the air-conditioner. Please note the above when you use it.
-

1-6. Data Analyzer

Function outline

This software displays a history graph of operating power consumption or time of air conditioners managed with Air Conditioning Control System. Comparison with previous data of the same conditioner, operating data of another air conditioner, floor, tenant, or other group units allows you to visually check the operating efficiency of the air conditioner.

In addition, when the use of the air conditioner is improved, e.g. when the energy saving priority operation (saving / demand control) is performed on the Air Conditioning Control System or when the set temperature is changed depending on the status, the software displays the energy saving efficiency in graph, which allows you to visually compare and check.

Table 1-1 Function outline

Function	Description	Note
Trend graph display	Displays a graph of operating power consumption or time of air conditioners managed with Air Conditioning Control System.	A graph can be displayed in day (in units of one hour), week (in units of one day), month (in units of one day), and year (in units of one month). In addition, a no-comparison graph can include outdoor temperature, indoor temperature, and set temperature.
Performance status display of saving operation / demand control	Displays a graph of the performance status of saving / demand for each unit.	Displayed for each indoor unit. (The demand control display targets an outdoor unit connected to an indoor unit displayed in graph.) The saving operation / demand control can only be displayed when a no-comparison trend graph for indoor unit single selection is set in units of one day.
Comparison with previous operating performance data in graph	Displays a graph of operating data of air conditioners managed with Air Conditioning Control System in units of air-conditioner or group. In addition, the reduction rate of power consumption for each hour can be displayed in % and in graph.	Comparison can be performed in units of unit or group such as floor and tenant. A graph can be displayed in day (in units of one hour), week (in units of one day), month (in units of one day), and year (in units of one month).
Ranking table of air-conditioners	Displays operating data of air conditioners managed with Air Conditioning Control System in a ranking list. Can be compared in units of air-conditioner or group.	The power consumption and operating time can be compared.
Alarm history display	Displays the alarm history in the specified period.	
Graph / Data export	Exports the displayed graph.	<ul style="list-style-type: none"> • Screen printing using the PC-connected printer • JPEG export • Graph screen copy to the clipboard • Data export for spreadsheet software Can be performed.

1-7. Remote monitoring


Settings for Remote Monitoring with a PC

You can monitor and control the Unit by accessing it from a PC. This section explains the settings for the Unit and the PC. Please see "9. Remote monitoring using a PC" (Owner's Manual P.74) for the system diagram and the PC operating environment.

NOTE

Some functions cannot be used from a PC. For details, please see "List by Lock Level/Level" (Owner's Manual P.84)

System diagram



Unit settings

- 1** Set the user account for remote operation (Owner's Manual P.66)
- 2** Set the IP address (Owner's Manual P.69)
- 3** Set a destination to send email to when an alarm occurs (Owner's Manual P.70)

PC settings

Settings

IP address/ Subnet mask	Set it to be the same network as the Unit. (For details, see the "Network Configuration Guide".) (Example: the Unit 192.168.2.80/PC 192.168.2.90/subnet 255.255.255.0)
Port	Release port number 8801.
Drive C	Ensure that you have 500 MB or more free space and start up as a user with read/write authority.

Operating Environment

The following environment is necessary to use this function.

OS	Windows 8.1, Windows 10
.NET Framework	4.6.2
Web browser	Microsoft Edge, Internet Explorer 11, Google Chrome latest version


Install the software

- 1 Open the web browser of your PC
- 2 Access "http://[server name or IP address]/touchscreencontroller/[language code]/download.html"

Server name or IP address : For the IP address, enter the value set in step 2 of "Unit settings" (P.32).

Language code : Enter the following value according to the language.

Language	Language Code
Japanese	JA
English	EN
French	FR
German	DE
Italian	IT
Spanish	ES
Portuguese	PT
Turkish	TR
Polish	PL
Chinese	ZH



- 3 Click [3-(1)]
- 4 Save the file according to the browser message
- 5 Double-click on the saved "installer_touchscreencontroller.exe" to unzip/install (setup.exe)

When the installation is completed, a shortcut icon is created on the desktop.



NOTE

If .NET Framework 4.6.2 is not installed on the PC, this software will not work properly. Be sure to download and install .NET Framework 4.6.2 from the above website.

Remote monitoring using a PC

You can monitor and control the Unit by accessing it from a PC. This section explains the system diagram and the operating environment. For settings, etc., see "Settings for Remote Monitoring with a PC" (P.32).

NOTE

Some functions cannot be used from a PC. For details, please see "List by Lock Level/Level" (Owner's Manual P.84).

Log in to Remote Control Software

NOTE

Up to 16 users can log in at the same time.




1 Double-click "AMTC_UI_****" on the desktop


2 Enter [User ID] [password], then click [2-(1)]

User ID/password:

Use the user account set up in step **1** of "Unit settings" (P.32).





The Remote Control Software home screen is displayed.




Log out from Remote Control Software

1 Click






2 Click [2-(1)]




3 Click [3-(1)]
You are logged out from the Remote Control Software.


Exit Remote Control Software



1 Tap [1-(1)]




2 Tap [2-(1)]



3 Tap [3-(1)]
Exit the Remote Control Software.

2 System Configuration


2-1. System configuration diagram




2-2. Outline drawing

■ Outline drawing

Air Conditioning Control System



Power adapter




3 Initial Settings

3-1. Create local information

When using the template function of the setting file creation software

- (1) Start the setting file creation software, select [Tool] - [Output Template] - [Touch Screen Controller(CT128series)], and output the template file.
- (2) Fill in each item of "Building Name" "IP Address" "Air Conditioner Information" and "Digital I/O Relay Interface" in the template file.



Template file sample

When not using the template function of the setting file creation software

- (1) Fill in each item of "Building Name" "IP Address" "Air Conditioner Information" and "Digital I/O Relay Interface" in Excel, etc.
* For details of each item, please refer to the input items of the above template file sample.

3-2. Create setting data with the setting file creation software

When using the template function of the setting file creation software

- (1) Start the setting file creation software. Select [Tool] - [Import] - [Touch Screen Controller(CT128series)], and import the template file data.

When not using the template function of the setting file creation software

(1) Start the setting file creation software. Select [New] - [Touch Screen Controller(CT128series)], Input each item entered in the work of "" into the setting file creation software settings screen.

*When using centralized controllers in combination (up to 8 units)

When using centralized controllers in combination including the Unit within the same TCC-LINK, apply the following settings.

When using multiple units of the Unit in combination (master/slave setting)

- The Unit - header unit (1 unit): No setting required
- The Unit - follower unit: Set to follower unit setting using the setting file creation software.

When using in combination with the TouchScreenController (BMS-CT512*)

- TouchScreenController (BMS-CT512*): No setting required
- The Unit: Set to follower unit setting using the setting file creation software.
Also, turn ON 1 of DS25 on the Communication settings screen of the main unit.

When using in combination with SmartBMS manager with data analyzer and a SmartBMS manager

- SmartBMS manager with data analyzer: No setting required
- The Unit: Set to follower unit setting using the setting file creation software.

3-3. Upload setting data

* If LAN connection is difficult after the installation work, please implement "3-3.Upload setting data" before "3-8.Installation work". If LAN connection is easy after installation work, "3-8.Installation work" may be implemented after "3-3.Upload setting data".

- (1) Confirm that the setting content matches the on-site system.
- (2) Connect the PC with the setting file creation software and the TouchScreenController main unit with a LAN cable.
- (3) Confirm that the HOME screen displays after turning on the main unit (after about 4 minutes).
- (4) Set the PC's IP address to the same network as the TouchScreenController such as 192.168.2.80.
- (5) Display "Upload setting" in [File] - [Upload] in the setting file creation software.
- (6) Confirm that it is connected to the TouchScreenController with the [ping] button.
- (7) Upload the setting file to the TouchScreenController with the "Upload" button.

3-4. Setting up by the controller only

With this controller (software version 10.1.7.0 and later), air-conditioning units can be registered and area names and other settings below can be configured without using the setting file creation software that is required for conventional setup. A conventional setup using the setting file creation software is necessary when other settings are required.

Setting items that can be configured by the controller (without using the setting file creation software)

No.	Setting Item	Setting Menu
1	Indoor unit registration	[Menu]-[Service settings]-[Central management address Setting]
2	Indoor unit area setting	[Menu]-[Indoor unit area setting]
3	Indoor unit name setting (single-byte alphanumeric characters only)	[Menu]-[Indoor unit name setting]
4	Area name setting (single-byte alphanumeric characters only)	[Menu]-[Area name setting]


3-5. Starting/exiting the service settings


[Service settings] is usually hidden. The following procedure can be used to display the [Service settings] and start the service menu.

[Service settings] enables manipulation of the following three items.


Item	Function
Cancel service mode	The service menu is exited, and the [Service settings] are hidden.
Communication	Communication settings can be configured.
Central management address Setting	The central management addresses and communication settings of the setting file of indoor units can be changed.

Starting the service settings





1 Tap 
[1-(1)] appears.

2 Scroll through the menu list and tap [2-(1)]
The Information screen appears.



3 Tap and hold the lower left and lower right of the Information screen at the same time for about five seconds


After the sections that were tapped and held turn green, tap  to return to the menu.



4 Tap [4-(1)]

The [Service settings] are displayed, and the service menu starts.

Exiting the service settings



1 Tap [1-(1)]


2 Tap [2-(1)]

The service menu is exited, and the [Service settings] are hidden.

3-6. Communication settings

The communication settings of TCC-LINK (DS25) can be changed. To change the settings, start the service settings using "3-5.Starting/exiting the service settings" (P.40).

Changing the communication settings



1 Tap [1-(1)] of the [Service settings] items

2 In [2-(1)], change the communication settings

Tap items to toggle between ON (top side) and OFF (bottom side).

3 Tap [3-(1)]

The changed content is confirmed.


<Communication settings of TCC-LINK (DS25)>

No. 1	No. 3	Used together with central controller*1		Connection of device without remote controller*2	Release or no release of the local remote control operation prohibition setting during recovery of an indoor unit power outage
		512-Line Touch Screen Controller	Non-512-Line Touch Screen Controller		
OFF	OFF	Not possible	Possible	Not possible	Released
OFF	ON	Setting prohibited (L20 (Central management address overlap) may be detected))			
ON	OFF	Possible	Not possible	Not possible	Released
ON	ON	Possible	Not possible	Possible	Not released


NOTE

*1 When a Non-512-Line Touch Screen Controller is used at the same time, follow the settings of [Used together with central controller] → [Non-512-Line Touch Screen Controller].

*2 When a local remote controller is not connected to the indoor unit, a "without remote controller" icon is displayed to the right of the indoor unit name.



Confirmation of power pulse




1 Tap [1-(1)] of the [Service settings] items

2 At the communication settings screen, swipe the empty space at the bottom from left to right

The confirmation screen for power pulse signals appears.

Power pulse signal confirmation screen



No.	Function
1	The watt hour meter to be displayed in the pulse table can be selected. In the case of the main unit and the watt hour meter IF, this is [128] and [128 + address number], respectively. The item can be switched by tapping the pulldown menu.
2	Shows the channel number.
3	Shows the pulse number configured by the setting file creation software.
4	Shows the input value of the pulse. The input count of the pulse can be checked by this section.
5	Shows the total value (for one day) for a daily report.
6	Shows the one-hour total value for the trend.

NOTE

The pulse table is updated in 30-second cycles because the power pulse signal is acquired by internal communication.

3-7. Central management address Setting


Using the [Central management address Setting], the central management addresses and setting file of the indoor units can be configured and changed.

To change the settings, start the service settings using "3-5.Starting/exiting the service settings" (P.40).


● **NOTE**

If you leave the Central management address Setting screen, a restart is required.

Setting and changing central management addresses



1 Tap [1-(1)] of the [Service settings] items




The following message appears: [Rebooting is necessary when it is executed. Is it OK?]

2 Tap [2-(1)]


Connection information is acquired. (This takes about five minutes.)


If the connection information is acquired, the Central management address Setting screen appears.



3 Using [3-(1)], tap a Central management address to be configured or changed

The Central management address selection screen appears.






4 Using [4-(1)], tap the Central management address to be configured or changed


NOTE

A blue vertical line appears to the left of the selected Central management address.



5 Tap [5-(1)]

The Central management address of the selected indoor unit is configured.




6 Tap [6-(1)]


The configured content is confirmed.

Automatic assignment

Central management addresses can be assigned automatically to all indoor units. Following section explains the automatic assignment procedure.



1 Tap [1-(1)] of the [Service settings] items





The following message appears: [Rebooting is necessary when it is executed. Is it OK?]

2 Tap [2-(1)]

Connection information is acquired. (This takes about five minutes.)

If the connection information is acquired, the Central management address Setting screen appears.





3 Select Central management addresses to be automatically assigned from [3-(1)]

If this is tapped, the following message appears: [Automatic assignment of TCC-LINK1 (or TCC-LINK2) will be performed. Continue?]

4 Tap [4-(1)]

Automatic assignment of the Central management address is performed for the selected TCC-LINK. (This takes about three minutes.)






- 5** Tap [5-(1)]
The configured content is confirmed.

Reacquisition

The connection information of the indoor units can be re-acquired. Following section explains the reacquisition procedure.

1 Tap [1-(1)] of the [Service settings] items





The following message appears: [Rebooting is necessary when it is executed. Is it OK?]

2 Tap [2-(1)]



Connection information is acquired. (This takes about five minutes.)


If the connection information is acquired, the Central management address Setting screen appears.



3 Tap [3-(1)]

Connection information is re-acquired. (This takes about five minutes.)





- 4** Tap [4-1]
The configured content is confirmed.


Setting file information

A setting file can be created based on acquired indoor unit connection information.

Indoor units can be registered without using the setting file creation software during installation of this controller, expansion of indoor units, or relocation of equipment.

Following section explains the procedure to create or change the setting file.

1 Tap [1-(1)] of the [Service settings] items





The following message appears: [Rebooting is necessary when it is executed. Is it OK?]

2 Tap [2-(1)]


Connection information is acquired. (This takes about five minutes.)

If the connection information is acquired, the Central management address Setting screen appears.




3 Tap [3-(1)]


The Automatic registration of indoor unit pop-up appears.



4 Select [4-(1)] or [4-(2)], and then tap [4-(3)]

Select [4-(1)] for [Initialize settings and create new] or select [4-(2)] for [Add, change without initializing settings (for expansion, relocation)].





The following message appears: [Rebooting is necessary when it is executed. Is it OK?]

5 Tap [5-(1)]

Automatic registration configuration is started. (This takes about five minutes.)

<Indoor unit automatic registration selection items>

Item	Content
Initialize settings and create new	<ul style="list-style-type: none"> Initialize settings and create a setting file based on connection information. All items such as indoor unit names and area information are deleted.
Add, change without initializing settings (for expansion, relocation)	<ul style="list-style-type: none"> Change the setting file based on connection information without initializing the setting file. The names for newly added indoor units are configured automatically. Items such as indoor unit names and area information are retained. Items that are not included in the newly acquired information are deleted from the setting file.

3-8. Installation work

Installs the main unit. For the installation method, refer to the installation manual that came with the product.

3-9. Trial operation

- (1) Confirm that the settings are reflected on the TouchScreenController(CT128) screen normally by switching ON/OFF, changing the set temperature, and changing the Mode from the remote control of each air conditioner.
- (2) From the TouchScreenController(CT128) screen, switch ON/OFF, change the set temperature, and change the Mode and confirm that the air conditioners operate normally.

4 Troubleshooting

Phenomenon	Question	Confirmation items
The LCD does not display.	Is the power turned on?	Check that the power is not turned off by the breaker or the like. There is a green LED at the lower rear of the main unit and a green LED on the AC adapter that indicate that power is being supplied. Check that the wiring of the power outlet and AC adapter is not disconnected. There is a green LED at the lower rear of the main unit and a green LED on the AC adapter that indicate that power is being supplied.
	Has the backlight gone out?	The LCD turns off when there is no operation for a certain period of time. Touch the touch panel to turn on. The brightness and display time can be changed using [Backlight].
	Is the backlight brightness dark?	Adjust the brightness using [Backlight].
The operated air conditioner does not run.	Does the operated air conditioner match the actual air conditioner?	Operate another air conditioner and check if the actual air conditioner operates.
	Is an alarm occurring?	The air conditioner will not operate when an alarm is occurring. Turn off the alarm.
	Are you operating with the local remote control?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Is the air conditioner stopped due to the schedule setting of the local remote control or the like?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control schedule, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Are you operating with the PC app "Remote Control Software"?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the PC app "Remote Control Software", it will stop. The latter operation of this Unit or the "Remote Control Software" overrides the former.
I want to turn off the power.	There is no power switch.	Please remove the AC adapter or turn off the circuit breaker.
I want to reboot.	Reboot from the menu.	Select [Menu] - [Functions] - [System reboot].
The air conditioner settings change arbitrarily.	Are you operating with the local remote control?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Is the air conditioner stopped due to the schedule setting of the local remote control or the like?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control schedule, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Have you applied settings such as stop using an external input signal?	When stop, etc. is set by an external input signal using the external interlocking function, the air conditioner stops automatically when a signal is input.
	Are you operating with the PC app "Remote Control Software"?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the PC app "Remote Control Software", it will stop. The latter operation of this Unit or the "Remote Control Software" overrides the former.
The schedule does not work.	Is the schedule disabled?	Please confirm the Scheduler Operation settings.
	Does the scheduled air conditioner match the actual air conditioner?	Operate another air conditioner and check if the actual air conditioner operates.
	Is a Particular Timer setting set?	If a day is set in both the Week Schedule and a Particular Timer setting, the Particular Timer setting will apply for that day.

Phenomenon	Question	Confirmation items
The air conditioner doesn't cool. The air conditioner doesn't heat.	Is demand control turned on?	Demand control suppresses the capability of the outdoor unit in order to reduce power consumption. Therefore, it may take time to reach the set temperature.
	Is the forced thermo OFF control turned on?	Forced thermo OFF is a control to stop the operation of the outdoor unit. Therefore, the indoor unit acts as a fan.
	Is the power saving control turned on?	Power saving suppresses the capability of the outdoor unit. Therefore, it may take time to reach the set temperature.
The LCD does not turn off.	Is an alarm occurring?	The LCD will still be on when an alarm is occurring. Turn off the alarm.
Sometimes the LCD becomes black for a moment.	The LCD's antistatic control is working.	Temporarily stop the LCD periodically to prevent LCD burn-in. Not a malfunction.
The setting displayed on the local remote control does not match the setting displayed on this Unit.	Does the operated air conditioner match the actual air conditioner?	Operate another air conditioner and check if the actual air conditioner operates.
I would like to frequently change detailed settings such as set temp. and setting mode for all air conditioners.	Only "ON" and "OFF" can operate all air conditioners at once.	You can set the set temp., setting mode, etc. for each air conditioner group by group. Please group the air conditioners.
When local remote control operation is prohibited, if there is a power failure, the local remote control prohibited status will be cancelled when the power returns.	Check [Menu] - [Service settings] - [Communication].	Set [Menu] - [Service settings] - [Communication] as follows. DS25-3... If you want to continue the local remote control prohibited status after returning from a power failure, please turn ON.
FILTER information can be reset even when the FILTER sign is not displayed.	The FILTER sign lights up depending on the accumulated operation time.	As the operation time accumulates, the FILTER sign lights up when the preset operation time is reached. The FILTER sign information can be reset to clear the accumulated time for cases such as when FILTER cleaning is carried out before the FILTER sign turns on.
I want to check the software version.	Reboot from the menu.	The version is displayed under [Menu] - [Information].
Reboot from time to time.	Please check for noise and the power supply status.	The main unit may restart if noise in the surroundings or an unstable power supply cause the operation of the software to be unstable. Please check the surrounding environment.
I cannot start the Remote Control Software.	Is "Error 1001" displayed?	Please download .Net Framework 4.6.2 from the download website of this software and install it.
	Is the LAN cable connected?	This software will not start unless the PC and the LAN of this Unit are connected. Check the LAN cable connection and network settings.
	Is the IP address of the access destination set to the IP address of the controller main unit?	The IP address (or server name) to be entered during installation is the IP address of the controller main unit. It is not the IP address of the PC. If it is incorrect, please do the following and then reinstall. 1. Uninstall the application 2. Delete the install destination directory 3. Delete the desktop and start menu shortcuts
	Is the PC on which the software was installed Windows 8.1 or 10?	Windows 8.1 and 10 are supported. The software may not operate correctly when installed on a PC with a different OS.
I cannot log in to the Remote Control Software.	Have you logged in as the same user from another PC?	Each user can log in from only one PC at the same time.
	Is the Windows display style set to classic style?	Please select a display style other than classic style. You can change the display style from [Start] - [Control Panel] - [Appearance and Personalization] - [Change the theme]. This software supports Windows 8.1 and 10.

Phenomenon	Question	Confirmation items
I cannot log in to Remote Control Software from another PC after the LAN is disconnected.	Have you logged in with the same user ID?	You must log in again from a PC with the LAN disconnected and log out normally.
	Have you accessed the software from more than 8 PCs?	Up to 8 PCs can be accessed at the same time. The software may not operate correctly if you connect to more than 9 PCs.
	Did you assign the PC's IP address using a DHCP server?	This Unit judges whether it is accessed from the same PC using the IP address. If the PC address is changed partway through by the DHCP server, you may not be able to log in again after LAN disconnection. Please set the PC that accesses this Unit to a fixed IP or reboot the Unit and erase the login information.
The language does not switch with the Remote Control Software.	Does the login user for the Windows being used have write permission for the Remote Control Software storage location?	Please allow write permission below the folder where Remote Control Software is saved (initial setting: C:\Program Files\TOSHIBA Carrier Corporation). Right-click on the TOSHIBA Carrier Corporation folder, select the [Properties] - [Security] Name, click the "Edit" button and check [Allow] for [Full control] under different settings.
The schedule setting changes have not been reflected.	Are you trying to change the schedule settings on both the Remote Control Software and the main unit?	To change the schedule settings, please set only one of either the main unit or the Remote Control Software.
I would like to use the software with other centralized controllers.	Centralized controllers that can be used together within the same TCC-LINK.	It is possible to use up to 8 units together with all centralized controllers including this Unit. Ask service personnel to use them in combination.
I would like to use the software with other centralized controllers.	Centralized controllers that can be used together within the same TCC-LINK.	It is possible to use up to 8 units together with all centralized controllers including this Unit. To use them in combination, please set [Menu] - [Service settings] - [Communication] as follows. DS25-1... Please turn this setting ON when using centralized controllers in combination.
I want to use multiple units in combination.	Number of units that can be used in combination in the same TCC-LINK.	It is possible to use up to 8 units together with all centralized controllers including this Unit. To use them in combination, please set [Menu] - [Service settings] - [Communication] as follows. DS25-1... Please turn this setting ON when using centralized controllers in combination.
The multi outdoor unit's option board control does not work.	Do you want to use the multi outdoor unit's option board?	When the centralized controller is connected, the functions of the outdoor unit's option board become ineffective. Only one of the centralized controller and the outdoor unit's option board can be used.
About communication settings in [Service settings].	Do you want to use centralized controllers in combination or use the local remote control prohibition settings?	If you change the setting to unnecessary, the Unit may not work properly. If it has been set, please return it to the initial value (only DS25-2 ON). The following settings should be used. DS25-1... To use centralized controllers in combination, turn this setting ON. DS25-3... If you want to continue the local remote control prohibited status after returning from a power failure, please turn this setting ON.
The Unit does turn ON/OFF even though the operation interlock signal/stop interlock signal is input.	Has the interlock signal been input from the time of activation?	Since the interlock signal confirms the state by detecting the rising edge and falling edge, if the interlock signal is input from the time of activation, interlock control will not be performed. Please set so that the interlock signal turns OFF at the time of activation.

5 Service Parts

No.	Component name	Component code	Overview	Q'ty
1	Power adapter	4316V581	Power supply adapter for Touch Screen Controller	1

Installation Manual


TOSHIBA

Air Conditioning Control System (Touch Screen Controller) Installation Manual

Model name:

BMS-CT1280E

BMS-CT1280E-TR



• Save These Instructions!

ENGLISH



- Thank you for purchasing the TOSHIBA air conditioning control system.
- Please read this installation manual carefully before installation, and perform the work only in the correct manner.

Contents





1	Precautions for safety	3
2	Specifications	5
3	Installation	8
3-1.	Installation of Main Unit Box and Panel	8
3-1-1.	When Installing from the Front	8
3-1-2.	When Installing from the Rear	9
3-2.	Attaching the Power Adapter	10
3-3.	Power, Signal, and Earth Line Connections	11

1 Precautions for safety




- Read these “Precautions for safety” carefully before installation.
- The precautions described below include important items regarding safety. Observe them without fail. Understand the following details (indications and symbols) before reading the body text, and follow the instructions.
- After the installation work has been completed, perform a trial operation to check for any problems. Explain how to use and maintain the unit to the customer.
Ask customer to keep this Manual at accessible place for future reference.

Indication	Meaning of Indication
 WARNING	Text set off in this manner indicates that failure to adhere to the directions in the warning could result in serious bodily harm (*1) or loss of life if the product is handled improperly.
 CAUTION	Text set off in this manner indicates that failure to adhere to the directions in the caution could result in serious bodily injury (*2) or damage (*3) to property if the product is handled improperly.

- *1: Serious bodily harm indicates loss of eyesight, injury, burns, electric shock, bone fracture, poisoning, and other injuries which leave aftereffect and require hospitalization or long-term treatment as an outpatient.
- *2: Bodily injury indicates injury, burns, electric shock, and other injuries which do not require hospitalization or long-term treatment as an outpatient.
- *3: Damage to property indicates damage extending to buildings, household effects, domestic livestock, and pets.

Symbols	Meaning of Symbols
	“  ” Indicates prohibited items. The actual contents of the prohibition are indicated by a picture or text placed inside or next to the graphic symbol.
	“  ” Indicates compulsory (mandatory) items. The actual contents of the obligation indicated by a picture or text placed inside or next to the graphic symbol.

WARNING

	<ul style="list-style-type: none"> • Ask an authorized dealer or qualified installation professional to install or reinstall this unit. Inappropriate installation may result in electric shock or fire. • Electrical work must be performed by a qualified electrician in accordance with this installation manual. The work must satisfy all local, national and international regulations. Inappropriate work may result in electric shock or fire. • Be sure to turn off all main power supply switches before starting any electrical work. Failure to do so may result in electric shock.
	<ul style="list-style-type: none"> • Do not modify the unit. A fire or an electric shock may occur.
	<ul style="list-style-type: none"> • Always connect to ground Improper grounding may result in an electric shock. Before connecting the power, carry out Class D grounding according to the “Engineering Standard for Electric Work” and the “Internal Wiring Regulations”.

Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

 **CAUTION**

- **Do not install in the following locations:**
 - Locations where combustible gas may leak
 - Locations with high humidity or water
 - Dusty locations
 - Locations in direct sunlight and locations subject to high temperatures
 - Locations within 1 m from televisions or radios
 - Outdoors, under awnings, or other locations exposed to rain and dew
 - Locations exposed to outside air containing corrosive gases or salinity
 - Locations with frequent vibrations
- **Do not operate the touch panel with mechanical pencils or other pointed objects.**



- **In installation work, use wiring with the correct ampacity.**
Failure to do so may result in excessive heat or fire.
- **Use specified cables and connect them securely, and do not subject connecting terminals to external force.**
Doing so may result in broken cables, excessive heat or fire.
- **Always install a circuit breaker on the primary side of the power supply.**
- **Clean the touch panel by wiping with an eyeglasses cleaner or other soft cloth.**
To remove oil-based ink, wipe with a cloth that has been moistened with a neutral detergent and then wrung out, and finish by wiping with a soft, dry cloth.
Do not use commercial OA cleaners, cleansers, or other liquid cleaners containing abrasives.
- **When attaching to a metal lath, wire lath or wooden structure with metal boards, attach it to the control panel, etc. without attaching it to the wall.**

CAUTION This device uses a lithium battery. Follow all local regulations when disposing of it.


2 Specifications

Product name		Touch Screen Controller
Model Name		BMS-CT1280E / BMS-CT1280E-TR
Power supply		220-240 V AC* 50/60 Hz
Number of connected units	Indoor unit	Up to 128 units (TCC-LINK 1 maximum 64 units, TCC-LINK 2 maximum 64 units)
	Power meter interface	Up to 4 units
	Digital I/O interface	Up to 4 units
Communication ports		<ul style="list-style-type: none"> •RS-485 port ×1 •LAN port ×1
USB port		USB memory stick connection port ×2
External contact input		8 inputs
External contact output		4 outputs
Operating temperature/humidity range		0°C to 40°C, 10% to 90% RH (no condensation)
Dimensions		H136×W205×D10 (+80) (Embedded dimensions shown in parenthesis)
Mass		1.34 kg (Touch Screen Controller) 0.45 kg (power adapter)


* Power cord for 220-240 V power adapter is to be arranged on site.

■ Outline drawing


Air Conditioning Control System



Power adapter



Component Names



Name	Function
12V DCIN	Connect the power adapter
Terminal block for external contact output	Connect the external contact output
Terminal block for external contact input	Connect the external contact input
TCC-LINK terminal block	Connect the TCC-LINK 1 and TCC-LINK 2 signal wires
RS-485 terminal block	Connect the RS-485 terminal block
USB	For service
LAN	Can be connected to a PC via LAN communication and monitored and controlled

■ Before Installation

Confirm that all the parts listed below are included in the package.

Included Items


No.	Component name	Quantity	Remarks
1	Main unit	1	
2	Power adapter	1	
3	Owner's Manual	1	
4	Installation Manual	1	
5	DVD-R	1	<Included Items> <ul style="list-style-type: none"> • Owner's Manual • Installation Manual • Network Configuration Guide • Data Analyzer • Report Creation Software • Section Changeover Software
6	Fixing screw	4	Fixing screw (M4×12) for attaching the main unit from the front
7	Fixing screw	4	Fixing screw (M3×8) for attaching the main unit from the rear
8	Closed end connector	2	RS-485 cable crimp connector
9	Binding band	2	For fixing the power adapter
10	Double-sided tape	1	For fixing the power adapter

Wiring specifications


Use the following wiring material to connect signal wires and power supply wires. (Locally procured)

No.	Wiring	Wire type / wire diameter / wire length
1	For TCC-LINK	Microphone cord (shielded) (two-core) for instrumentation
		1.25 mm ² , up to 1000 m (total extension distance)
		2.00 mm ² , up to 2000 m (total extension distance)
2	For RS-485	Microphone cord (shielded) (two-core) for instrumentation
		1.25 mm ² , up to 500 m (total extension distance)
3	For digital I/O	Two-core cable 0.3 mm ² , up to 100 m
4	For Ethernet	LAN cable (category 5 or above) Maximum length: 100 m


3-1-2. When Installing from the Rear



**Air conditioning control system to wall, etc.
fixing hole dimensions**



Hole dimensions to drill in wall




* Although the panel and the main unit box are separated to explain the screw attachment part in an easy to understand manner, it is not necessary to remove the main unit box from the panel in actual installation work.

- 1** Drill four $\text{Ø}4$ holes in the switchboard, wall, etc.
- 2** Fit the main unit on the switch board, wall, etc.
- 3** Fix from the rear of the main unit. Please use the supplied $\text{M}3 \times 8$ screws.
- 4** Connect the TCC-LINK cable, AC adapter, and LAN cable to the main unit.
- 5** When installation is completed, peel off the transparent film.


3-2. Attaching the Power Adapter

The power adapter can be installed on a flat surface or on a wall. Do not install it in any other orientation. Fix with the attached binding band and double-sided tape.

Installation allowed



Installation not allowed



* Install so that the power cable that connects to 220-240 V AC does not face upward.

REQUIREMENT

Do not install in the following locations.


- Locations with high humidity or water
- Dusty locations
- Locations in direct sunlight and locations subject to high temperatures
- Locations within 1 m from televisions or radios
- Outdoors, under awnings, or other locations exposed to rain and dew

3-3. Power, Signal, and Earth Line Connections

Connect the power, signal and earth lines to the specified terminal blocks.


REQUIREMENT

Attach round crimp terminals to all TCC-LINK 1, TCC-LINK 2, and RS-485 wiring, and tighten the screws securely. After tightening, check that the wiring cannot come out.




EN


TCC-LINK communication line stripping length



RS-485 cable wire stripping length





Digital I/O cable stripping length



Attach a round crimp terminal to each wire of the power line and signal line.

Loosen the screws with a screwdriver, insert the digital I/O cable, and tighten the screws securely.



Termination resistance setting

- RS-485 termination resistance settingSet at both ends of the RS-485 communication line. Set one end at the main unit and the other end at the interface. The termination resistance of the main unit is already set as a factory default. Refer to the interface installation manual to set the termination resistance of the interface.
- TCC-LINK termination resistance settingSet on the air conditioner. The TCC-LINK termination resistance is not set in the main unit. Leave "open".

Shield grounding process















- RS-485 cable wire shielded wire Connect to the FG terminal block.
- TCC-LINK communication cable shielded wireWhen using the air conditioning control system with one unit, open the shielded wire of the TCC-LINK communication cable and perform insulation processing.
When using the air conditioning control system with multiple units, connect the shield of the TCC-LINK communication line to the closed end and open the shield at the final end of the air conditioning control system to perform insulation processing.
Perform TCC-LINK communication line shield grounding on the air conditioner side.

REQUIREMENT

- Be sure to install a circuit breaker or all-pole isolating switch (with a contact breaking distance of at least 3 mm) on the primary side of the power supply.
- Fasten the screws to the terminal block with torque of 0.5 N•m.

■ Connection to External Devices

Example of connection to external equipment which is connected to digital input/output terminal.

Name	I/O Item	Air conditioning control system side		External device side	
		I/O conditions	Terminal name	Circuit example	I/O conditions
DO1 Output common	State output	Contact permissible voltage/current 24 V DC/35 mA	DO1 		Wiring length: Within 100 m
DO2 Output common			DO2 		
DO3 Output common			DO3 		
DO4 Output common			DO4 		
DI1 Input common	Control input	No-voltage contact A Pulse or static * No-voltage contacts compatible with very small current should be selected 5 V DC/3 mA	DI1 		Pulse width: 50 msec or more Wiring length: Within 100 m
DI2 Input common			DI2 		
DI3 Input common			DI3 		
DI4 Input common			DI4 		
DI5 Input common			DI5 		
DI6 Input common			DI6 		
DI7 Input common			DI7 		
DI8 Input common			DI8 		

- * Wire the cables so that the user does not touch the power supply directly.
- * On the external device side, use a basically insulated power circuit and place it in a location where the user cannot touch it.

EN

■ Wiring connections


This section shows wiring connection examples with the indoor units, power meter interface, digital I/O interface, and remote monitoring PC.

Air conditioning unit group settings

- Indoor units can be set together for each group unit.
- There is a TCC-LINK 1 and a TCC-LINK 2 for each TCC-LINK communication line. There are 64 groups in each line, and there are 128 groups and 128 zones for TCC-LINK 1 and TCC-LINK 2 together.

Interface connection

Connect the power meter interface and the digital I/O interface to the RS-485 cable line. For details of the connection method refer to the interface installation manual.



Gr = Group


NOTE

Set the termination resistance of TCC-LINK 1 and 2 at the air conditioner.
When you remove the rear panel of this Unit, there is SW100 which is the termination resistance of TCC-LINK 1 and 2.
In both cases, please use in the "Open": OFF state.

Network Configuration Guide

Model name:

BMS-CT1280E



Never connect the Touch Screen Controller to the Internet.
We assume no responsibility for any problems resulting from connection to the Internet.
Only local area connection is allowed for the Touch Screen Controller.

This guide describes the setting procedure for connecting the Touch Screen Controller to your personal computer (abbreviated to “PC” hereinafter) via the network.
PC operation to monitor and control air conditioners is detailed in the Owner’s Manual.

1. System configuration of PC

The client PC to be connected must meet the following system configuration conditions so that the Touch Screen Controller operates normally.

<Operating system>

Must be either of the following

- Windows 8.1
- Windows 10

<Hardware>

- Screen resolution 1366 × 768 pixels or more

<Browser>

Must be either of the following

- Internet Explorer 11
- Google Chrome
- Microsoft Edge

2. Connecting LAN cable


Connect the LAN cable to the LAN1 connector on the Touch Screen Controller.

3. Client PC settings


3-1. Setting IP address

- 1) Log on to the system with the PC administrator’s account.
- 2) Click [Start] -> [Control Panel]. (Fig.1)

Fig.1




- 3) Click [Network and Sharing Center]. (Fig.2)



- 4) Click “Local Area Connection” of View your active networks. (Fig.3)




- 5) Click [Properties] in the Local Area Connection Status window. (Fig.4)




- 6) Select the “Internet Protocol Version 4 (TCP/IPv4)” checkbox, and click [Properties]. (Fig.5)

Fig.5



- 7) Select the “Use the following IP address:” radio button, and set as follows:
 IP address: 192.168.2.*** (***: Excluding 80)
 Subnet mask: 255.255.255.0.
 Then click [OK]. (Fig.6)

Fig.6




- 8) Close all the windows.

3-2. Setting browser <Internet Explorer>


- 1) Start Internet Explorer.
- 2) Click the [Tools] button.
- 3) Choose “Internet Options” from the pull-down menu.
- 4) Click the “Connections” tab. (Fig.1)

Fig.1



- 5) Click [LAN settings]. (Fig.2)

Fig.2



- 6) Clear the “Use a proxy server for your LAN” checkbox (Fig.3) or select the “Bypass proxy server for local addresses” checkbox (Fig.4), and then click [Advanced].

Fig.3






Fig.4



Add “192.168.2.80” to the “Do not use proxy server for addresses beginning with:” field. (Fig.5)

Fig.5




Now the configuration operations are completed. For the subsequent operations, refer to the Owner's Manual.

Owner's Manual

Touch Screen Controller

Model Name

BMS-CT1280E
BMS-CT1280E-TR



- Thank you for purchasing this air conditioning control system.
- In order to use this product safely and correctly, please read this operation manual carefully before use and make sure that you fully understand the contents.
In particular, please be sure to read the "Safety Precautions".
- After reading this manual, be sure to keep it in a place where the operator of the Unit can always view it.

Contents

1 Quick Start Guide	6
2 Safety Precautions	7
3 Operating method and screen structure.	9
Touch Panel Operation Method	9
Screen Structure	10
4 Before Usage	11
Air Conditioning System Configurations	11
Control Target Devices	12
About the Main Screens	13
Home	13
Screen description	13
Group control screen ([CONTROL] tab)	16
How to display the screen	16
Screen description	17
Individual control screen ([CONTROL] tab)	18
How to display the screen	18
Screen description	19
5 Perform initial settings	21
Unit Settings	21
Settings for Remote Monitoring with a PC	21
System diagram	21
Unit settings	22
PC settings	22
Settings	22
Operating Environment	22
Install the software	23
Settings when Using Report Creation Software.	24
Unit settings	24
PC settings	24
Settings when Using the PC Software Data Analyzer	24
Unit settings	24
PC settings	24
6 Basic Usage	25
Start/Stop Operation	25
Overall air conditioning system operation method	25
Group unit operation method	26
Operation method in units of air conditioner or ON/OFF unit	27

Change the Air Conditioning Settings	
(ON/OFF/Mode/Wind direction/Fan Speed/Set temp.)	28
Group unit operation method	28
Air conditioner unit operation method	31
Set the Operation Schedule	33
Screen description	33
Group screen	33
Individual control screen	34
Create a new Week Schedule	35
Create a new Particular Timer setting	37
Monitor the Overall Air Conditioning System.	39
7 Various Functions.	40
Local Remote Controller Lock	40
Set Operation Details	42
Turn ON/OFF the ventilation function (Ventilation → ON/OFF)	44
Set Ventilation Mode (Ventilation → Mode)	44
Setting the ventilation fan speed (Ventilation → Fan speed)	44
Check the output status of the air conditioner(s) (Power Level)	45
Check the indoor temperature detected by the outdoor unit (Outdoor temp.)	45
Erase FILTER Sign (Filter sign reset)	45
Set Middle COOL (Soft Cooling)	45
Control air conditioner power (Energy saving ratio [%])	46
Release Thermo OFF (Forced Thermo OFF)	46
Configure and confirm the Return Back settings (Return Back)	46
Monitor demand control of outdoor unit (Power peak cut)	46
Change to energy saving temperature (Eco Temperature Shift)	47
Set the temperature change range (Set temp. range limit)	47
Change the Operating Schedule	48
Change the details of the Week Schedule	48
Change the details of the Particular Timer setting	50
Setting items list	52
Delete the operation schedule	54
Confirm the Operation Time.	55
Group screen	55
Individual control screen	55
8 Administrator menu	56
Restrict Operation of the Touch Screen Controller (Operation Lock)	56
Confirm Alarm History (Alarm history)	57
Confirm the Power consumption on a Graph (Power consumption)	58
[Functions] Menu Settings	59
How to display the [Functions] menu	59
Release demand control of outdoor unit (Release power peak cut)	59
Set demand control schedule of outdoor unit (Power peak cut schedule)	60

Add/change Power peak cut schedule	60
Delete an Power peak cut schedule	62
Restrict operation mode (Operation mode restriction)	62
Restart the Unit (System reboot)	62
Set the operating schedule or the power peak cut schedule (Scheduler Operation)	63
Output data to a USB memory stick (Output to USB memory)	63
[Initial setting] Menu Settings	63
How to display the [Initial setting] menu	63
Set the screen display (Display)	64
Set the current date and time (Clock and calendar)	64
Set icons of devices other than air conditioners (Icon)	65
Set the screen theme (Theme)	65
Set an account for remote operation (User Account)	66
Add/change user account	66
Delete a user account	67
Set the operation lock level (Operation lock)	68
Set the IP address of the Touch Screen Controller (IP Address)	69
Set alarm email destination (Alarm email address)	70
Change the area set for an indoor unit (Indoor unit area setting)	71
Set the name of an indoor unit (Indoor unit name setting)	72
Set the area name (Area name setting)	72
Set the screen brightness (Backlight)	73
9 Remote monitoring using a PC	74
Log in to Remote Control Software	74
Log out from Remote Control Software	74
Exit Remote Control Software	75
10 Power allocation	76
Electric Power Allocation System that can be Used with this Unit	76
Power Allocation System	77
Set the summation date of the power allocation data (Automatic Meter-Reading)	77
Sum data for power allocation as necessary (Manual Meter-Reading)	78
How to use the power allocation system	78
11 Troubleshooting	79
12 Useful information	82
13 Appendix	82
Specifications	82
Detailed specifications	82
Function list	83
Glossary	84
List by Lock Level/Level	84

14	Warranty and after-sales service	86
	About the Warranty	86
	About After-Sales Service	86
	Contact for after-sales service (Information)	86
	OSS License	87

1 Quick Start Guide





Basic Usage		
To start/stop the air conditioner(s)		→ "Start/Stop Operation" (P.25)
To change the set temperature		→ "Change the Air Conditioning Settings (ON/OFF/Mode/Wind direction/Fan Speed/Set temp.)" (P.28)
To change the Mode (Cool/Heat/Auto/Dry/Fan)		→ "Change the Air Conditioning Settings (ON/OFF/Mode/Wind direction/Fan Speed/Set temp.)" (P.28)
To check whether you have forgotten to turn off the air conditioner(s)	Batch ON/OFF screen	→ "Monitor the Overall Air Conditioning System" (P.39)
To check for current alarms	Alarm history screen	→ "Monitor the Overall Air Conditioning System" (P.39)

Advanced Usage <small>Please use the following functions as necessary.</small>		
To set start/stop timer		→ "Set the Operation Schedule" (P.33)
To configure and confirm the energy saving settings	Return Back	→ "Configure and confirm the Return Back settings (Return Back)" (P.46)
	Eco Temperature Shift	→ "Change to energy saving temperature (Eco Temperature Shift)" (P.47)
	Change Temperature Range	→ "Set the temperature change range (Set temp. range limit)" (P.47)
	Save Mode	→ "Control air conditioner power (Energy saving ratio [%])" (P.46)
	Schedule settings	→ "Set the Operation Schedule" (P.33)
	Power peak cut schedule	→ "Set demand control schedule of outdoor unit (Power peak cut schedule)" (P.60)
To operate the Total Heat Exchange Unit		→ "Turn ON/OFF the ventilation function (Ventilation → ON/OFF)" (P.44)
To cancel the FILTER Sign after filter cleaning		→ "Erase FILTER Sign (Filter sign reset)" (P.45)
To connect with a PC that has the PC software Data Analyzer installed and display the usage of energy	Connect with the PC that has the PC software Data Analyzer installed and display the energy usage	→ "Settings when Using the PC Software Data Analyzer" (P.24)
	IP Address Setting	→ "Set the IP address of the Touch Screen Controller (IP Address)" (P.69)
	Output to USB memory	→ "Output data to a USB memory stick (Output to USB memory)" (P.63)
To connect with a PC that has Report Creation Software installed and display the power usage report	Connect with a PC that has Report Creation Software installed and display the power usage report	→ "Electric Power Allocation System that can be Used with this Unit" (P.76)
	Automatic Meter-Reading	→ "Set the summation date of the power allocation data (Automatic Meter-Reading)" (P.77)
	Manual Meter-Reading	→ "Sum data for power allocation as necessary (Manual Meter-Reading)" (P.78)
	IP Address Setting	→ "Set the IP address of the Touch Screen Controller (IP Address)" (P.69)
To output the daily and monthly report files, the alarm files, and the setup files by USB		→ "Output data to a USB memory stick (Output to USB memory)" (P.63)

2 Safety Precautions

This section explains safety precautions you must follow in order to prevent harm to the user and other persons and damage to property.



"Display Description" explains the classification of the degree of harm or damage that may occur if the unit is handled incorrectly, while "Symbol Description" indicates the meanings of symbols.

Display Description	Symbol Description
 WARNING Indicates "Content that is expected to result in death or serious injury (*1) to the user in the case of incorrect handling".	 ⊘ indicates prohibited actions. Specifically prohibited contents are indicated with a picture and/or text in or near the symbol.
 CAUTION Indicates "Content that is expected to result in minor injury (*2) to the user or damage to property (*3) in the case of incorrect handling".	 ● indicates instructions which must be followed. The actual contents of the instructions are indicated with a picture and/or text in or near the symbol.





* 1: Serious injury refers to lasting after effects such as blindness, injury, burns (high temperature / low temperature), electric shock, bone fracture, or poisoning, etc. and injuries that require hospitalization/long-term outpatient treatment.
 * 2: Minor injury refers to injuries, burns, or electric shocks, etc. that do not require hospitalization or long-term outpatient treatment.
 * 3: Damage to property refers to extended damage related to houses, household goods, livestock, or pets, etc.

⚠ WARNING




Installation Precautions

 Request installation Ask the dealer from whom you purchased the unit or a professional for installation work. Installation requires specialised technical expertise. If you attempt to perform installation work yourself and perform the work incorrectly, it may cause fire, electric shock, or injury.	 Use specified products Use a designated TOSHIBA air conditioner. Please use a designated TOSHIBA air conditioner. Using products other than specified may cause fire, electric shock, or water leakage. Also, please ask a professional for installation work.
--	--

Usage Precautions





 Prohibited Do not operate the switches with wet hands. Doing so may cause electric shock or failure.	 Prohibited Do not wet the Air Conditioning Control System. Please be careful not to get the Air Conditioning Control System wet. Doing so may cause fire, electric shock, or failure.
 Compulsory Turn off the power if anything is abnormal (burnt odour etc.). Continued use may cause fire or electric shock. Please ask the dealer from whom you purchased the product.	 Compulsory Do not use a power source other than the specified model. Using a power source other than the specified model may cause fire or failure. Please use 220 V AC.

Relocation/Repair Precautions




 Prohibited Do not remodel. Doing so may cause fire or electric shock.	 Request Please ask the dealer from whom you purchased the unit for repair. Faulty repair may cause fire or electric shock.
 Request relocation Contact a specialist or the dealer from whom you purchased the unit to relocate and re-install the air conditioner. Faulty installation may cause fire, electric shock or injury.	

⚠ CAUTION

Installation Precautions

 Check the installation location	<p>Do not install in areas with high humidity or vibration. Doing so may cause a failure.</p>	 Check the installation location	<p>Do not install in direct sunlight or near heat sources. Doing so may cause a failure.</p>
 Check the installation location	<p>Do not install in areas where noise is generated. Doing so may cause malfunction.</p>	 Check the installation location	<p>Do not install the air conditioner in a place where combustible gas may leak. Gas leaking and accumulating around the product may cause a fire.</p>

Usage Precautions

 Prohibited	<p>Do not drop the product or apply strong shock. Doing so may cause a failure.</p>	 If anything is abnormal turn off the power	<p>If anything is abnormal, stop operation and turn off the original power supply, then contact the dealer from whom you purchased the unit. Continued operation with an abnormality may cause fire or electric shock.</p>
 Instructions	<p>When cleaning and checking, turn off the earth leakage breaker. Failing to do so may cause injury.</p>		


3 Operating method and screen structure

Touch Panel Operation Method

Explains the basic touch panel operation method.


Tap

Touch your finger lightly on the screen and release it immediately.




Drag

Tap an object on the screen, hold your finger down, and move.




Swipe

Touch your finger lightly on the screen and move it in the desired direction.




Flick

Touch the screen with your finger and move your finger quickly up, down, to left or the right.



Screen Structure

The main screen structures used by this Unit are as follows. The screen can be switched by tapping (or flicking in some cases).



Each display is an example screen. The display content varies with the usage environment settings.


Home screen	You can check the operation status of the air conditioner(s) and ON/OFF unit in a list. You can also start/stop individual operation. (P.13)	
Group screen	You can check/change the settings in group units. The group screen consists of three tabs: "CONTROL", "SCHEDULE" and "GRAPH". (P.16)	
Individual control screen	You can check/change the settings of the air conditioner(s) and ON/OFF unit individually. The individual control screen consists of three tabs: "CONTROL", "SCHEDULE" and "GRAPH". (P.18)	
Batch ON/OFF screen	You can check the operation status of the whole air conditioning system numerically. You can also start/stop the operation of the whole air conditioning system and configure the detailed settings. (P.39)	
Alarm history screen	You can confirm alarms that are occurring in the whole air conditioning system in a list. (P.39)	
[CONTROL] tab	You can check the detailed operation status. You can change the settings such as ON/OFF. (P.25)	
[SCHEDULE] tab	You can control the Week Schedule and the Particular Timer setting. (P.35)	
[GRAPH] tab	Group screen	You can check the operation time in group units. (P.55)
	Individual control screen	You can check the operation time in air conditioner or ON/OFF unit in units. (P.55)
Menu	You can configure settings for administrators such as screen display change and demand control. (P.56)	

4 Before Usage

Air Conditioning System Configurations

The system configurations that this Unit can control are as follows:

All
Set all air conditioners at once.








Unit
Set the air conditioners individually.


Group
All air conditioners and ON/OFF unit are divided into 1 to 128 groups, and settings are configured for each group at once. It is convenient to register the air conditioners by dividing them into groups for each room.

- There are three units that can be controlled: All, Group, and Unit.
- The maximum number of groups (Floor/Tenant/Area combinations) that can be controlled is 128.
- The maximum number of units that can be controlled (air conditioner(s) and ON/OFF unit) is 128 for air conditioners and 60 for ON/OFF unit.

Control Target Devices

In this Unit, the following devices can be controlled and monitored.

Device names shown in this manual	Target devices	
<p>Air conditioner</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> You can set air conditioning and heating operation </div> <p>(128 units)</p>	<ul style="list-style-type: none"> • Multi air conditioners for buildings (Ceiling cassette, ceiling embedded, ceiling hanging, air to air heat exchanger with coil, etc.) • Custom air conditioners for stores and offices • Package air conditioners for facilities • Hot Water Module (* For use outside Japan only) • DX-Coil Interface TA type (* For use outside Japan only) 	
<p>ON/OFF unit</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> You cannot set air conditioning or heating operation (Operation can be turned ON/OFF.) </div> <p>(60 units)</p>	<ul style="list-style-type: none"> • Air to Air Heat Exchanger • General purpose device control interface • External device (DI/DO) (Air to Air Heat Exchanger, Lighting, Ventilation fan, etc.) 	   




About the Main Screens

This section explains the home screen and the [CONTROL] tab of the group screen/individual control screen.

NOTE


The language and display colors of the screen differ depending on the language and theme settings. The screens shown in the manual use the [English] language setting and the [Type A] theme setting. For details of the theme settings, refer to "Set the screen theme (Theme)" (P.65).

















Home




































Screen description


Switches for all air conditioners and ON/OFF unit are displayed for each group. You can change the group displayed by scrolling the screen.




No.	Name (Icon)	Functions										
1	Header area	It is displayed even on screens other than the home screen. The operation content is common to each screen.										
2	Menu button (☰)	<p>Tap to display the menu. You can display various reports and detailed settings for the Unit.</p> <p>NOTE</p> <p>The display content of the menu may partially differ depending on the conditions.</p> 										
3	ON/OFF meter button (⏻/⏿)	Tap to display the batch ON/OFF screen. (P.39) Lights up when there is an air conditioner or ON/OFF unit in operation.										
4	Alarm button (🚨/🚨)	Tap to display the alarm history screen. (P.39) Lights up red when an alarm has occurred.										
5	Status display section	<p>Displays the current date and time. Also, the following will be displayed depending on the status and settings of the air conditioning system.</p> <table border="1"> <tr> <td></td> <td>Displays when a demand signal is detected.</td> </tr> <tr> <td></td> <td>Displays during demand control of an outdoor unit. (P.60)</td> </tr> <tr> <td></td> <td>Displays when you operate remotely from a computer. (P.74)</td> </tr> <tr> <td></td> <td>Displays while outputting data to a USB memory stick. (P.63)</td> </tr> <tr> <td></td> <td>Displays when the daylight saving time (summer time) setting is ON. (P.64)</td> </tr> </table>		Displays when a demand signal is detected.		Displays during demand control of an outdoor unit. (P.60)		Displays when you operate remotely from a computer. (P.74)		Displays while outputting data to a USB memory stick. (P.63)		Displays when the daylight saving time (summer time) setting is ON. (P.64)
	Displays when a demand signal is detected.											
	Displays during demand control of an outdoor unit. (P.60)											
	Displays when you operate remotely from a computer. (P.74)											
	Displays while outputting data to a USB memory stick. (P.63)											
	Displays when the daylight saving time (summer time) setting is ON. (P.64)											
6	Group name display section	Displays the name of the group that displays the switch (the name of the group to which the displayed switch belongs). Tap the underlined name in the group name to display the drop-down menu. You can jump to other groups.										
7	"FORWARD" button (➤)	Tap to display the group screen. (P.16)										

No.	Name (Icon)	Functions																				
8	Switch	<p>The air conditioner or ON/OFF unit switch registered in each group is displayed, and the name is displayed below the switch.</p> <table border="1"> <tr> <td data-bbox="643 349 786 640">  </td> <td data-bbox="786 349 1453 640"> <p>Displays the operation status of the air conditioner(s). 24.0°C means operating state. The set temperature is displayed on the left and the operation mode is displayed on the right. Drag or flick to the left to stop the operation.  is the stopped state. Only the set operation mode is displayed. Drag or flick to the right to start the operation. Tap the overall switch to switch to the [CONTROL] tab on the individual control screen. (P.18)</p> </td> </tr> <tr> <td data-bbox="643 640 786 775">  </td> <td data-bbox="786 640 1453 775"> <p>Displays the operating condition of the air conditioner. Operation of the air conditioner(s) is locked. (P.56)</p> </td> </tr> <tr> <td data-bbox="643 775 786 853">  </td> <td data-bbox="786 775 1453 853"> <p>Alarm in progress. Tap to switch to the [CONTROL] tab on the individual control screen and check the details of the alarm. (P.20)</p> </td> </tr> <tr> <td data-bbox="643 853 786 931">  </td> <td data-bbox="786 853 1453 931"> <p>Operation is impossible due to power outage (hibernation state).</p> </td> </tr> <tr> <td data-bbox="643 931 786 1055">  </td> <td data-bbox="786 931 1453 1055"> <p>Displays the operation status of the ON/OFF unit. Drag left or right to change the operation status.</p> </td> </tr> <tr> <td data-bbox="643 1055 786 1155">  </td> <td data-bbox="786 1055 1453 1155"> <p>Displays the operation status of the ON/OFF unit. The operation status cannot be changed. The Unit is locked or output control cannot be performed.</p> </td> </tr> <tr> <td data-bbox="643 1155 786 1245">  </td> <td data-bbox="786 1155 1453 1245"> <p>Displayed when the FILTER Sign appears.</p> </td> </tr> <tr> <td data-bbox="643 1245 786 1346">  </td> <td data-bbox="786 1245 1453 1346"> <p>Displayed during operation preparation.</p> </td> </tr> <tr> <td data-bbox="643 1346 786 1447">  </td> <td data-bbox="786 1346 1453 1447"> <p>Displayed during heating preparation.</p> </td> </tr> <tr> <td data-bbox="643 1447 786 1547">  </td> <td data-bbox="786 1447 1453 1547"> <p>Displayed when the output of the air conditioner is limited.</p> </td> </tr> </table>		<p>Displays the operation status of the air conditioner(s). 24.0°C means operating state. The set temperature is displayed on the left and the operation mode is displayed on the right. Drag or flick to the left to stop the operation.  is the stopped state. Only the set operation mode is displayed. Drag or flick to the right to start the operation. Tap the overall switch to switch to the [CONTROL] tab on the individual control screen. (P.18)</p>		<p>Displays the operating condition of the air conditioner. Operation of the air conditioner(s) is locked. (P.56)</p>		<p>Alarm in progress. Tap to switch to the [CONTROL] tab on the individual control screen and check the details of the alarm. (P.20)</p>		<p>Operation is impossible due to power outage (hibernation state).</p>		<p>Displays the operation status of the ON/OFF unit. Drag left or right to change the operation status.</p>		<p>Displays the operation status of the ON/OFF unit. The operation status cannot be changed. The Unit is locked or output control cannot be performed.</p>		<p>Displayed when the FILTER Sign appears.</p>		<p>Displayed during operation preparation.</p>		<p>Displayed during heating preparation.</p>		<p>Displayed when the output of the air conditioner is limited.</p>
	<p>Displays the operation status of the air conditioner(s). 24.0°C means operating state. The set temperature is displayed on the left and the operation mode is displayed on the right. Drag or flick to the left to stop the operation.  is the stopped state. Only the set operation mode is displayed. Drag or flick to the right to start the operation. Tap the overall switch to switch to the [CONTROL] tab on the individual control screen. (P.18)</p>																					
	<p>Displays the operating condition of the air conditioner. Operation of the air conditioner(s) is locked. (P.56)</p>																					
	<p>Alarm in progress. Tap to switch to the [CONTROL] tab on the individual control screen and check the details of the alarm. (P.20)</p>																					
	<p>Operation is impossible due to power outage (hibernation state).</p>																					
	<p>Displays the operation status of the ON/OFF unit. Drag left or right to change the operation status.</p>																					
	<p>Displays the operation status of the ON/OFF unit. The operation status cannot be changed. The Unit is locked or output control cannot be performed.</p>																					
	<p>Displayed when the FILTER Sign appears.</p>																					
	<p>Displayed during operation preparation.</p>																					
	<p>Displayed during heating preparation.</p>																					
	<p>Displayed when the output of the air conditioner is limited.</p>																					


Group control screen ([CONTROL] tab)



How to display the screen



- 1 Scroll the home screen to display the group you want to change the settings for, then tap >




NOTE

You can jump to another group in the drop-down menu displayed by tapping the group name.


The [CONTROL] tab of the group screen is displayed.

Screen description




No.	Name (Icon)	Functions
1	Group name	Displays the name of the currently displayed group. Tap to display the drop-down menu. You can switch the display to the individual control screen for another air conditioner or ON/OFF unit registered in the group. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: 20px;"> 1F_Bookstore 2F_Bookstore 3F_General Store 4F_General Store </div>
2	Setting	You can change overall settings of the group such as Mode, set temperature, air direction, and fan speed simultaneously. (P.28)
3	ALL ON/ALL OFF	You can turn the whole group ON/OFF simultaneously. (P.26)
4	Next screen	Tap to display the individual control screen of the air conditioner or ON/OFF unit registered in the group. You can flick the group screen to display it.
5	Display position	Only the number of air conditioners or ON/OFF unit registered in the group <input type="checkbox"/> is displayed. For the currently displayed screen, <input checked="" type="checkbox"/> is displayed.
6	[SWITCH] tab	Tap to switch to the "6-(1)", "6-(2)" or "6-(3)" tab of the group screen.
7	Run	The ON/OFF meter on the left side can be used to check the total number of units operated in the group. On the right side you can check the number of units in each operation mode. The upper row shows the number of units in operation and the lower row shows the number of units stopped. If there are devices that do not have an operation mode, they will be displayed in [Other].
8	"BACK" button()	Returns to the Home.

Individual control screen ([CONTROL] tab)




How to display the screen



- 1** Scroll the home screen, display the air conditioner or ON/OFF unit that you want to change the settings for, then tap the switch


The [CONTROL] tab of the individual control screen is displayed.

Screen description




Each display is an example of the screen in the case of an air conditioner.
The display contents varies with use environment settings.

No.	Name (Icon)	Functions
1	Group name	The name of the air conditioner or ON/OFF unit currently displayed is shown. Tap to display the drop-down menu. You can switch the display to the group screen or another air conditioner or ON/OFF unit registered in the group. <div style="float: right; border: 1px solid black; padding: 5px; margin-top: 10px;"> 1F_Bookstore 2F_Bookstore 3F_General Store 4F_General Store </div>
2	Next screen	Tap to display the individual control screen for other air conditioners or ON/OFF unit registered in the group. You can also flick and display the individual control screen being displayed.
3	Lock setting of remote control	You can restrict the operating range of the local remote controller of the air conditioner(s) or ON/OFF unit. (P.40) If it is not restricted, [👉] is displayed. If there are restricted items, [🚫] is displayed.
4	option	You can set or confirm the details of the operation method. (P.42)
5	Display position	Only the number of devices registered in the group [] is displayed. For the currently displayed screen, [] is displayed.
6	[SWITCH] tab	Tap to switch to the "6-(1)", "6-(2)" or "6-(3)" tab of the individual control screen.
7	Setting area	You can change basic settings such as operation mode, set temperature, air direction, and fan speed. (P.31)
8	ON/OFF	Tap to switch between ON/OFF.
9	Previous screen	Tap to display the individual control screen for other air conditioners or ON/OFF unit registered in the group. You can also flick and display the individual control screen being displayed. The group screen appears at the beginning.
10	"BACK" button(<)	Returns to the home screen.


NOTE

- For ON/OFF unit, only configurable items are displayed.

Icons are displayed only when they are registered. (P.65)



- If an error occurs, an alarm code is displayed. Operation other than operation ON/OFF is not possible.



- Operation is impossible due to power outage (hibernation state).

5 Perform initial settings

Unit Settings

Have service personnel perform the following work.

1 Check the installation and wiring of the main unit

Follow the installation instructions to complete the installation and wiring work.

2 Check the wiring between the remote controller, indoor unit, and outdoor unit

Check that the address from the remote controller to the Unit is correct, and switch ON/OFF, Cool/Heat and confirm that operation is normal.

3 Create a local setting file with the setting file creation software

Input necessary information based on local air conditioner information and display language settings, etc. into a PC on which the setting file creation software is installed to create a local settings file.

4 Upload the local settings file

Connect the Unit to the PC via LAN and upload the local settings file.
While uploading, the Unit restarts.

5 Confirm the setting contents

Check that the screen display of the Unit is set according to the local settings file, perform ON/OFF, and confirm that the Unit operated on the screen matches the Unit that actually starts to operate.


Settings for Remote Monitoring with a PC

You can monitor and control the Unit by accessing it from a PC. This section explains the settings for the Unit and the PC. Please see "9. Remote monitoring using a PC" (P.74) for the system diagram and the PC operating environment.

NOTE

Some functions cannot be used from a PC. For details, please see "List by Lock Level/Level" (P.84)

System diagram



Unit settings

- 1** Set the user account for remote operation (P.66)
- 2** Set the IP address (P.69)
- 3** Set a destination to send email to when an alarm occurs (P.70)

PC settings

Settings

IP address/ Subnet mask	Set it to be the same network as the Unit. (For details, see the "Network Configuration Guide".) (Example: the Unit 192.168.2.80/PC 192.168.2.90/subnet 255.255.255.0)
Port	Release port number 8801.
Drive C	Ensure that you have 500 MB or more free space and start up as a user with read/write authority.

Operating Environment

The following environment is necessary to use this function.

OS	Windows 8.1, Windows 10
.NET Framework	4.6.2
Web browser	Microsoft Edge, Internet Explorer 11, Google Chrome latest version


Install the software

- 1** Open the web browser of your PC
- 2** Access "http://[server name or IP address]/touchscreencontroller/[language code]/download.html"

Server name or IP address : For the IP address, enter the value set in step **2** of "Unit settings" (P.22).

Language code : Enter the following value according to the language.

Language	Language Code
Japanese	JA
English	EN
French	FR
German	DE
Italian	IT
Spanish	ES
Portuguese	PT
Turkish	TR
Polish	PL
Chinese	ZH



- 3** Click [3-(1)]
- 4** Save the file according to the browser message
- 5** Double-click on the saved "installer_touchscreencontroller.exe" to unzip/install (setup.exe)

When the installation is completed, a shortcut icon is created on the desktop.



NOTE

If .NET Framework 4.6.2 is not installed on the PC, this software will not work properly. Be sure to download and install .NET Framework 4.6.2 from the above website.

Settings when Using Report Creation Software

By using the Report Creation Software, you can easily check/output reports (monthly report/daily report) for electric power allocation summed by the Unit with a PC. When using the Report Creation Software, apply the following settings.

• NOTE

For details on how to use the Report Creation Software, refer to the operation manual of the Report Creation Software.

Unit settings

- 1 Set the IP address of the Unit (P.69)**
- 2 Set the summation date for the power allocation data using the Unit (P.77)**

PC settings

- 1 Install the Report Creation Software on the PC**
For details, refer to the "Installation Instructions" included in the attached DVD.
- 2 Register the target system (this Unit) in the Report Creation Software**
For details, refer to the operation manual of the Report Creation Software.

Settings when Using the PC Software Data Analyzer

When using the PC software Data Analyzer, you can display the operation status and operation history of the air conditioners aggregated by this Unit on a PC screen.

• NOTE

For details on how to use the PC software Data Analyzer, refer to its operation manual.

Unit settings

- 1 Set the IP address of the Unit (P.69)**

PC settings


- 1 Install the PC software Data Analyzer on the PC**
For details, refer to the "Installation Instructions" included in the attached DVD.
- 2 Register the target system (this Unit) in the PC software Data Analyzer**
For details, refer to the operation manual of the PC software Data Analyzer.

6 Basic Usage


This section explains the basic setting method for operation Start/Stop and air conditioning, the setting method for the operation schedule, and the confirmation method for the overall air conditioning system.

Start/Stop Operation


Overall air conditioning system operation method




1 Tap  



2 Tap [2-(1)] or [2-(2)]




3 Check the contents of the message and tap [3-(1)]




4 When the screen on the left appears, check the contents of the message and tap [4-(1)] or [4-(2)] *

All air conditioners and ON/OFF unit start/stop operation.


* About confirmation pop-up selection




Group unit operation method




1 Scroll the home screen to display the group you want to change the settings for, then tap >



2 Tap [2-(1)] or [2-(2)]




3 Check the contents of the message and tap [3-(1)]



4 When the screen on the left appears, check the contents of the message and tap [4-(1)] or [4-(2)] *

All group air conditioners and ON/OFF equipment turn ON or OFF.


* About confirmation pop-up selection



Operation method in units of air conditioner or ON/OFF unit




1 Scroll the home screen and display the air conditioner or ON/OFF unit that you want to change the settings for



2 Drag or flick the of the corresponding switch

Drag or flick to the right to start operation.
Drag or flick to the left to stop operation.




NOTE


You can also start/stop operation by tapping the power icon on the [CONTROL] tab on the individual control screen displayed by tapping the switch.

Change the Air Conditioning Settings (ON/OFF/Mode/Wind direction/Fan Speed/Set temp.)


Group unit operation method



1 Scroll the home screen to display the group you want to change the settings for, then tap >




2 Tap [2-(1)]
The batch settings screen is displayed.



3 Change settings

Example: When changing the operation status settings

3-1 Tap [3-(1)]
The operation status settings screen is displayed.






3-2 Set the check box of [3-(2)] to
You can now change the settings.

3-3 Select [3-(3)] or [3-(4)] and tap [3-(5)]
Return to the batch settings screen.


3-4 Change the other items with reference to steps 3-1 to 3-3
For the setting details, see the following table.

No.	Name	Functions
1	ON/OFF	Can be set to [ON/OFF].
2	Mode	Can be set to [Auto/Heat/Dry/Cool/Fan]. NOTE <ul style="list-style-type: none"> A bar is displayed at the bottom of the icon for the currently selected mode. Operation modes that cannot be set are not displayed.


No.	Name	Functions
3	Wind direction	<p>Tap ◀ ▶ to switch to the following.</p>  <p>• NOTE</p> <p>Depending on the connected model, items that cannot be set are not displayed.</p>
4	Fan Speed	<p>Tap ◀ ▶ to switch to the following.</p>  <p>• NOTE</p> <ul style="list-style-type: none"> For models with limited fan speed setting range, this is changed to the values that can be set for each model. Fan speeds that cannot be set are not displayed.
5	Set temp.	<p>Tap ▲ ▼ to change the set temperature.</p> <p>• NOTE</p> <ul style="list-style-type: none"> When set to a temperature outside the setting range limit of each operation mode, the temperature is changed to the upper or lower limit of the setting range. If there are Dual Set Point compatible models in the group, two tabs will be displayed. When you tap [3-(6)], one set temperature is displayed, and when you tap [3-(7)], two set temperatures are displayed. Tap ▲ ▼ to change the set temperature. An icon and a message are displayed here during frost protection preparation, heat preparation or other operations. 

• **NOTE**


- For models that do not have the function set, the setting change is ignored.
- For the setting of [Lock] [Unlock] of [3-(8)], see "Local Remote Controller Lock" (P.40).
- For the [Option] settings of [3-(9)], see "Set Operation Details" (P.42).



4 Confirm that the changed item is checked, and tap [4-(1)]




5 Check the contents of the message and tap [5-(1)]



6 When the screen on the left appears, check the contents of the message and tap [6-(1)] or [6-(2)] *
The settings of the entire group are changed.


*** About confirmation pop-up selection**



Air conditioner unit operation method

NOTE


To change the settings, it is necessary to set to the operation status. (P.27)




1 Scroll the home screen, display the air conditioner you want to change the settings for, then tap the switch



2 Change settings

No.	Name	Functions						
1	Mode	<p>Can be set to [Auto/Heat/Dry/Cool/Fan].</p> <p>NOTE</p> <ul style="list-style-type: none"> A bar is displayed at the bottom of the icon for the currently selected mode. Operation modes that cannot be set are not displayed. 						
2	Wind direction	<p>Tap to switch to the following.</p>  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Operation Mode</th> <th style="width: 50%;">Setting Range</th> </tr> </thead> <tbody> <tr> <td>Auto (Cool)/Cool/Dry</td> <td>Swing ON→Swing OFF→F1→F2→F3→Swing ON (Return to the beginning)</td> </tr> <tr> <td>Auto (Heat)/Heat/Fan</td> <td>Swing ON→Swing OFF→F1→F2→F3→F4→F5→Swing ON (Return to the beginning)</td> </tr> </tbody> </table> <p>NOTE</p> <ul style="list-style-type: none"> The setting range varies depending on the operation mode. There is a function to set only [Swing ON]. 	Operation Mode	Setting Range	Auto (Cool)/Cool/Dry	Swing ON→Swing OFF→F1→F2→F3→Swing ON (Return to the beginning)	Auto (Heat)/Heat/Fan	Swing ON→Swing OFF→F1→F2→F3→F4→F5→Swing ON (Return to the beginning)
Operation Mode	Setting Range							
Auto (Cool)/Cool/Dry	Swing ON→Swing OFF→F1→F2→F3→Swing ON (Return to the beginning)							
Auto (Heat)/Heat/Fan	Swing ON→Swing OFF→F1→F2→F3→F4→F5→Swing ON (Return to the beginning)							

No.	Name	Functions
3	Fan Speed	<p>Tap to switch to the following.</p>  <p>• NOTE</p> <p>Fan speeds that cannot be set are not displayed.</p>
4	Set temp.	<p>Tap ▲ ▼ to change the set temperature.</p> <p>• NOTE</p> <ul style="list-style-type: none"> • If the operation mode is FAN, the temperature cannot be set. • "Control temp." shows the indoor temperature detected by the outdoor unit. *Depending on conditions such as the installation site of the indoor unit, it may differ from actual room temperature.

• **NOTE**


- For the setting of [(1)], see "Local Remote Controller Lock" (P.40).
- For the setting of [(2)], see "Set Operation Details" (P.42).
- If there is no corresponding function, that item is not displayed.

Example of a model without a flap



Since you cannot set the air direction, it does not change even if you tap it.

Example of a model where only a certain fan speed can be set



Since you cannot change the fan speed, it does not change even if you tap it.

Set the Operation Schedule

You can configure the air conditioners or the ON/OFF unit with a “Week Schedule”, through which settings such as operation start/stop are changed depending on the specified time for any day from Sunday to Saturday, or a “Particular Timer setting”, through which settings are changed for special days such as national holidays or special holidays. The operation schedule is set on the [SCHEDULE] tab of the group screen or individual control screen.

• NOTE

If a day is set in both the Week Schedule and the Particular Timer setting, the Particular Timer setting applies and the Week Schedule is disabled for that day.

Screen description


This section explains how to view the [SCHEDULE] tab when setting the operation schedule.

• NOTE

Refer to the description of the [CONTROL] tab for the display items that are not explained. (P.16, 18)

Group screen


The schedule set for the air conditioners or ON/OFF unit in the group is displayed in list format in time units.



No.	Functions
1	You can switch the display in day-of-week units.
2	Displays the setting screen of Particular Timer setting.
3	Displays the setting screen of Week Schedule.
4	The schedule settings content (ON/OFF, Mode, Temp., Lock, more) is displayed.
5	The times when the schedule is executed and the air conditioners and ON/OFF unit for which the schedule is executed is displayed.

Individual control screen

The schedule set for the air conditioner or ON/OFF unit being displayed is displayed on a 24-hour time scale.




No.	Functions
1	You can switch the display in day-of-week units.
2	Displays the setting screen of Particular Timer setting.
3	Displays the setting screen of Week Schedule.
4	🕒 is displayed at the times when the schedule is set. When operation start/stop is set, [ON] or [OFF] is displayed below 🕒. When setting change is set, ⚙️ is displayed below 🕒. Also, the currently displayed schedule is displayed in blue.
5	The schedule settings content (ON/OFF, Mode, Temp., Lock, more) is displayed.
6	You can switch the display to the previous or next schedule.
7	The times when the schedule will be executed are displayed.
8	The schedule setting number is displayed.

Create a new Week Schedule


In a Week Schedule, you can set:

- Start time
- Day(s) of the week
- Air conditioner(s) or ON/OFF unit
- ON/OFF


Schedule settings can be applied from either the group screen or the individual control screen. In the following procedure, the individual control screen is used to explain.




1 Tap [SCHEDULE] on the group screen or individual control screen




2 Tap [2-(1)]




3 Tap +



4 Tap or flick to set the start time and tap [4-(1)]




5 Select the day of the week to execute and tap [5-(1)]




6 Select the air conditioner(s) or ON/OFF unit for setting the schedule and tap [6-(1)]

You cannot select a model that has already been scheduled at the same time.



7 Tap the check box of [7-(1)] and set it to , then select [7-(2)] or [7-(3)] and tap [7-(4)]

You can only set [ON/OFF] here.



A schedule has been registered.


NOTE

- When setting details such as operation mode or set temperature, etc. as a schedule, refer to "Change the Operating Schedule" (P.48).
- When deleting a registered schedule, refer to "Delete the operation schedule" (P.54).


Create a new Particular Timer setting

In a Particular Timer setting, you can register special days, such as national holidays and special holidays, to configure a special schedule that differs from the Week Schedule.


Schedules can be configured from the group screen or the individual control screen. The following procedure is explained using the individual control screen.




1 Tap [SCHEDULE] on the group screen or the individual control screen



2 Tap [2-(1)]




3 Tap >



4 Tap [4-(1)] and set the schedule name


A keyboard is displayed. Enter the name and then tap [4-(2)].



5 Tap + to go to step 6

NOTE

- Tap [Shift] to toggle between upper case letters and lower case letters, and numbers and symbols.
- Tap to delete one character.




6 Tap or flick to set the start date, and then tap [6-(1)]



7 Tap the check box of [7-(1)] and set it to , then select [7-(2)] or [7-(3)] and tap [7-(4)]

You can only set [ON/OFF] here.




The schedule is registered.

NOTE

- When setting details such as the mode or the set temperature to a schedule, refer to "Change the details of the Particular Timer setting" (P.50).
- When deleting a registered schedule, refer to "Delete the operation schedule" (P.54).

Monitor the Overall Air Conditioning System

To check the operation status of the overall air conditioning system, tap / to display the batch ON/OFF screen.
 To check the alarm occurrence status, tap / to display the alarm history screen.




No.	Functions
1	Displays the overall number of operating units as ON/OFF meters and numerical values.
2	Displays the number of units for each operation mode. The upper row shows the number of units in operation and the lower row shows the number of units stopped. If there is ON/OFF unit, it is displayed in [Other].
3	You can change the operation status of the overall air conditioning system. (P.25) For the Option settings, see step 3 on (P.28).
4	Tap to close the batch ON/OFF screen. NOTE You can also tap / to close.
5	The alarm code, alarm content, occurrence location, and occurrence time are displayed.
6	Stop operation of all air conditioners and ON/OFF unit where alarms have occurred and erase the alarm(s). NOTE For some ON/OFF unit, only the operation stops, and the alarm(s) are not erased.
7	Stop the applicable air conditioner(s) or ON/OFF unit and erase the alarm(s). NOTE For some ON/OFF unit, only the operation stops, and the alarm(s) are not erased.
8	Tap to close the alarm history screen. NOTE You can also tap / to close.

7 Various Functions

This section explains detailed settings on the [CONTROL] tab, how to change the schedule on the [SCHEDULE] tab, and how to check the power usage on the [GRAPH] tab.


Local Remote Controller Lock

You can restrict operation of the local remote controllers that belong to each air conditioner.



- 1 Display the [CONTROL] tab of the air conditioner(s) whose setting you want to change (P.16,18)
When changing in group units, display the batch settings screen (P.28)


In the following procedure, the [CONTROL] tab of the individual control screen is used to explain.



- 2 Tap [2-(1)]

• NOTE


👉 appears if it is not locked. 🚫 appears if there is a locked item.



- 3 Tap the check box of the function whose setting you want to change to set it to

• NOTE

The display items vary depending on the model.



- 4 Select [4-(1)] or [4-(2)], then tap [4-(3)]

• REQUIREMENT

If you set the check box to before tapping [4-(3)], the setting will not be applied.

NOTE

When local remote control operation is prohibited, if there is a power failure, the local remote control prohibited status will be cancelled when the power returns.



Ask service personnel if you want to continue the local remote control prohibited status after returning from a power failure.

NOTE

If you perform an operation that is locked with the local remote controller, the lock screen or a message will be displayed.

**Lock screen example
(Energy saving neo remote
controller)**

(Wired remote controller)




Set Operation Details


You can check the current settings of the air conditioner(s) or ON/OFF unit, and set the details of the operation method.

- 1 Display the [CONTROL] tab of the air conditioner(s) or ON/OFF unit whose setting you want to change (P.18)
When changing in group units, display the batch settings screen (P.28)

In the following procedure, the individual control screen is used to explain.



- 2 Tap [2-(1)]



The option screen appears.

No.	Functions
1	The function name appears.
2	The currently set contents are displayed. If the settings are invalid, "-" is displayed.
3	When the settings can be changed, > is displayed. Tap to display the settings screen.

- 3 Scroll up and down to display the items you want to set/check

4 To change, tap > to display the settings screen, then tap [OK] after changing the settings

For details on the confirmation/setting contents of each item, refer to the following. The items displayed depend on the model and state.

Function Name	Overview	Setting Items	Reference Page
Ventilation → ON/OFF	Controls the operation of the ventilator connected to the air to air heat exchanger(s) or the air conditioner(s).	ON/OFF	P.44
Ventilation → Mode	Controls the ventilation mode of the ventilator connected to the air to air heat exchanger(s) or the air conditioner(s).	Bypass/Heat exchange/ Automatic	P.44
Ventilation → Fan speed	Controls the operation of the ventilator connected to the air to air heat exchanger(s) or the air conditioner(s).	High/Middle/ Supply air > Exhaust air/ Exhaust air > Supply air	P.44
Ventilation → Control	24-hour ventilation/Nighttime heat purge	–	–
Power Level	You can monitor the output status of the air conditioner(s).	–	P.45
Outdoor temp.	You can monitor the temperature inside the room detected by the outdoor unit.	–	P.45
Filter sign reset	You can clear the FILTER Sign. You can clear the Hour.	OK/Cancel	P.45
Soft Cooling	You can set to Middle COOL.	ON/OFF	P.45
Energy saving ratio [%]	You can control the cooling/heating output of the air conditioner(s).	Release/Max./50/0	P.46
Forced Thermo OFF	You can release Thermo OFF.	Invalid	P.46
Return Back	You can monitor Return Back. Return Back is set by the operation schedule.	–	P.46
Power peak cut	You can monitor whether the outdoor unit is controlling demand.	–	P.46
Eco Temperature Shift	You can set whether to change (shift) the set temperature.	Shift the set temperature to the energy saving temperature	P.47
Set temp. range limit	You can change the set temperature range for each operation mode.	18°C to 29°C * It may differ depending on the region and model.	P.47

Turn ON/OFF the ventilation function (Ventilation → ON/OFF)




You can turn ON/OFF the operation of the ventilator connected to the air to air heat exchanger(s) or air conditioner(s).

• **NOTE**
 Displayed when a configurable model is connected.

Set Ventilation Mode (Ventilation → Mode)

You can set the ventilation mode of the ventilator connected to the air to air heat exchanger(s) or the air conditioner(s). The settings screen displayed differs depending on the setting state of [Ventilation → ON/OFF].

◆ **When [ON] is selected under [Ventilation → ON/OFF]**



Bypass: Outdoor air is taken into a room as it is. We recommend using this mode in the middle of spring and autumn.


Heat exchange: Exchanging heat between the outdoor air and return air and making the temperature and humidity of the outdoor air closer to those of the return air before supplying it. We recommend you use this mode for cooling and heating in summer and winter.

Automatic: Total Heat Ventilation and Bypass Ventilation are switched automatically.

• **NOTE**

- Depending on the connected model, items that cannot be set are not displayed.
- Some items may not be configurable.

Setting the ventilation fan speed (Ventilation → Fan speed)




You can set the ventilation fan speed of the ventilator connected to the air to air heat exchange unit or the air conditioner. The choices displayed depend on the model.

• **NOTE**

- Displayed when a configurable model is connected.
- It is displayed when [Ventilation → ON/OFF] is [ON] and setting change is possible.

* Imbalance between ventilation and exhaust varies depending on the settings of the connected model.


Check the output status of the air conditioner(s) (Power Level)



You can check how much power the air conditioner is using for operation.

- **NOTE**
Displayed in the case of a compatible air conditioner.


Check the indoor temperature detected by the outdoor unit (Outdoor temp.)



You can check the temperature inside the room detected by the outdoor unit.

- **NOTE**
 - Displayed in the case of a compatible air conditioner.
 - Depending on conditions such as the location of the indoor unit installation, it may differ from the actual indoor temperature.

Erase FILTER Sign (Filter sign reset)



When a device has operated for a certain period of time, a warning (FILTER Sign) is displayed to indicate that the filter should be cleaned. After filter cleaning, tap [(1)].

- **NOTE**
 - Displayed in the case of a compatible air conditioner.
 - If you set the air conditioners where a sign is displayed to [OK], the cumulative time for the sign display is set to 0.

Set Middle COOL (Soft Cooling)



Middle COOL can be turned ON/OFF. When turned ON, the air direction is set to up, and the maximum power is restricted.

- **NOTE**
 - Displayed when a configurable model is connected.
 - The settings screen is displayed when the air conditioner is in operation and the operation mode is COOL.

Control air conditioner power (Energy saving ratio [%])

An energy saving function whereby you can operate the air conditioner with suppressed cooling/heating power.

Release: Save Mode is not performed.

Max.: Operate with the highest save rate.

50: Operate at 50% save rate.

0: Operate at 0% cooling/heating power (Thermo OFF).

● NOTE

The settings screen is displayed when a compatible air conditioner is in operation.

Release Thermo OFF (Forced Thermo OFF)

"Thermo OFF" refers to an energy saving function that controls demand to restrict the cooling/heating power of the air conditioner such that the outdoor unit compressor is stopped. When this state is reached, the air conditioner becomes a fan and cold/hot air is no longer output.

To release Thermo OFF, display the settings screen and press [OK].

● NOTE

Displayed in the case of a compatible air conditioner.

Configure and confirm the Return Back settings (Return Back)

You can configure and check the Return Back setting temperature and setting time of each operation mode that are set in the operating schedule.

● NOTE

- Displayed in the case of a compatible air conditioner.
- For information on Return Back, see "Return Back settings" (P.53).

Monitor demand control of outdoor unit (Power peak cut)

You can monitor the demand rate [%], outdoor line No., and schedule No. of the outdoor unit connected to the selected air conditioner.

Display the settings screen to check the demand status of the outdoor unit.

● NOTE

Displayed in the case of a compatible air conditioner.

Change to energy saving temperature (Eco Temperature Shift)

An energy saving function that changes (shifts) the set temperature according to the current operation mode as follows.

Operation Mode	Set Temperature Shift Width
Cool/Dry	Current set temperature +2°C shift
Heat	Current set temperature -2°C shift
Auto/Fan	Remain at current set temperature

NOTE


- Displayed in the case of a compatible air conditioner.
- When the Mode is set to [Heat], [Cool], or [Dry], the settings screen is displayed.

Set the temperature change range (Set temp. range limit)

You can set the set temperature range for each operation mode.

NOTE


- Displayed in the case of an air conditioner. It is not displayed in the case of ON/OFF unit.
- If the current set temperature of the air conditioner is outside of the set temperature range after the change, it will be changed to the temperature within the range after the change.



1 Tap the upper/lower limit temperature you want to change

NOTE

- Displayed in the case of a compatible air conditioner.
- Some operation modes are not displayed depending on the model.



2 Tap the number, enter the temperature, and tap [2-(1)]


Change the Operating Schedule

The operating schedule settings can be changed from the [Menu] button, the group screen, or the individual control screen. There are two types of operating schedules: Week Schedule and Particular Timer setting. The following procedure is explained using the individual control screen.


NOTE

If a day is set in both the Week Schedule and the Particular Timer setting, the Particular Timer setting applies and the Week Schedule is disabled for that day.


Change the details of the Week Schedule




1 Tap [1-(1)] on the group screen or the individual control screen



2 Tap [2-(1)]



3 Tap > of the schedule you want to modify




4 Modify the target air conditioner(s) or ON/OFF unit, then tap [4-(1)]




- 5** Scroll the screen and tap the value of the item you want to set. After changing the setting, tap [OK]
See "Setting items list" (P.52) for the items that can be configured.


Change the details of the Particular Timer setting




1 Tap [1-(1)] on the group screen or the individual control screen




2 Tap [2-(1)]




3 Tap > of the schedule you want to modify




4 Tap [4-(1)] to switch to the Assign screen




5 Modify the target air conditioner(s) or ON/OFF unit, then tap [5-(1)]




6 Tap the date you want to configure, modify the settings, and then tap [6-(1)]



7 Tap > of the schedule you want to modify













8 Tap > of the time you want to modify



9 Scroll the screen and tap the value of the item you want to set. After changing the setting, tap [OK]
See "Setting items list" (P.52) for the items that can be configured.


Setting items list

Setting Items	Setting Procedure
<p>Time setting [Start date]</p> 	<p>Tap or flick to change the time.</p>
<p>Day of the week setting [week]</p> 	<p>Set the check box(es) of the day(s) of the week on which you want to execute the schedule to <input checked="" type="checkbox"/>.</p> <p>NOTE</p> <p>The day of the [week] setting is not displayed in Particular Timer setting.</p>
<p>Operation setting [ON/OFF]</p> 	<p>To enable the setting, set the check box of [(1)] to <input checked="" type="checkbox"/> and select a value.</p>
<p>Operation mode setting [Mode]</p> 	<p>To enable the setting, set the check box of [(2)] to <input checked="" type="checkbox"/> and select a value.</p>
<p>Set temperature setting [Set temp.]</p> 	<p>To enable the setting, set the check box of [(3)] to <input checked="" type="checkbox"/>, tap ▲ ▼, then change the set temperature.</p>


Setting Items	Setting Procedure
<p>Return Back settings [Return Back]</p> 	<p>An energy saving function whereby if you temporarily change the set temperature to one which increases the load, you can automatically return to the energy saving set temperature after a certain time has elapsed. For example, if you set COOL to 28°C/30 minutes, then if the set temperature is set to below 28°C, the Unit will return to 28°C 30 minutes after the change.</p> <p>NOTE</p> <p>Displayed in the case of a compatible air conditioner.</p>
<p>Local operation prohibition setting [Lock setting of remote control]</p> 	<p>Tap the check box of the function whose setting you want to change to set it to <input checked="" type="checkbox"/>, then select [(1)] or [(2)].</p>
<p>Save operation setting [Energy saving ratio[%]]</p> 	<p>To enable the setting, set the check box of [(3)] to <input checked="" type="checkbox"/>. For details, see "Control air conditioner power (Energy saving ratio [%])" (P.46) .</p>
<p>Ventilation operation setting [Ventilation -> ON/OFF]</p> 	<p>You can turn ON/OFF the operation of the ventilator connected to the air to air heat exchanger(s) or air conditioner(s). To enable the setting, set the check box of [(4)] to <input checked="" type="checkbox"/> and apply the setting.</p>
<p>Vent. Mode [Ventilation -> Mode]</p> 	<p>You can set the ventilation mode of the ventilator connected to the air to air heat exchanger(s) or the air conditioner(s). To enable the setting, set the check box of [(5)] to <input checked="" type="checkbox"/> and apply the setting. For details, see "Set Ventilation Mode (Ventilation → Mode)" (P.44).</p>

Delete the operation schedule

You can delete the schedule from either the group screen or the individual control screen. In the following procedure, the individual control screen is used.




1 Tap [1-(1)] on the group screen or individual control screen




2 Tap [2-(1)] to go to step 4

3 (In case of Particular Timer setting) tap [3-(1)] Tap > of the schedule you want to modify to go to step 4.




4 Tap

(Some displayed items differ between the Week Schedule screen and the Particular Timer setting screen, but the procedure shown below is the same.)




5 Set the check box of the schedule you want to delete to then tap [5-(1)]



Confirm the Operation Time

In the [GRAPH] tab of the group screen or individual control screen, you can check the operation time for each group, air conditioner or ON/OFF unit. You can find the peak period of operation and waste operation.




1 Tap [1-(1)] on the group screen or individual control screen

The operation graph appears.


Group screen



Individual control screen



No.	Functions
1	The hourly or daily operation hours are shown as a bar graph. For the individual control screen, the outdoor temperature, room temperature, and set temperature are displayed as a line graph.
2	The operation hours for the displayed summary period is displayed.
3	Displays the currently displayed date. Tap ◀ ▶ to switch the date. Tap the centre to select the display period from the calendar screen.
4	You can change the summary unit to day or month.
5	The legend for the graph appears.



NOTE

Refer to the description of the [CONTROL] tab for other displays. (P.16, 18)


8 Administrator menu

Restrict Operation of the Touch Screen Controller (Operation Lock)

You can restrict the operation range of the Unit by locking it.

This section explains how to set and release the lock.


For the restriction range, see "Set the operation lock level (Operation lock)" (P.68).



1 Tap [1-(1)] appears.

2 Tap [2-(1)]

Below, the screen for release is explained.



3 Tap [3-(1)]
To change the auto lock settings, tap [3-(2)]



4 Tap the number, enter the 4-digit password, then tap [4-(1)]

The lock is set or released.

NOTE

- The initial set password is "1048".
- There are two levels of protection when locking. (P.68)
- Tap to delete one character.

NOTE


- You can change the password. (P.68) If you do not know the password, please contact your administrator.
- If you enter the wrong password three times when unlocking, password input is restricted for 30 minutes.
- When automatic lock is set, the Unit will be locked automatically after 5 minutes have passed after an operation has completed.
- When the lock is set, if you tap a function that cannot be operated, the message "operation function is locked" is displayed. Also, appears in the menu.

Confirm Alarm History (Alarm history)

You can display alarms that have occurred in a list, including currently occurring alarms. This can be used for grasping the status of the site such as investigating the cause of an alarm and the recovery status.

NOTE

The past 1000 alarms are displayed.



1 Tap [1-(1)] appears.

2 Tap [2-(1)]

3 The alarm history screen appears

The detected alarms are listed in chronological order.

Date/Time	Group	Area	Unit	Code
2018/10/29 19:08	1F Bookstore	cashier	AC001	E07
Communication circuit error between indoor/outdoor				
2018/10/29 19:08	1F Bookstore	cashier	AC001	E06
2018/10/29 19:07	1F Bookstore	cashier	AC001	E04
2018/10/29 19:07	1F Bookstore	cashier	AC001	E03

Currently occurring alarms are displayed with a red background.


Past alarms are displayed with a white background.

Tap to display the details of the alarm contents.

Confirm the Power consumption on a Graph (Power consumption)


Pulse values are graphed and the electric power can be visually confirmed.

* This function can be displayed when the electric power is measured by connecting this Unit to a pulse oscillation type watt hour meter.



1 Tap [1-(1)] appears.

2 Tap [2-(1)]




3 Tap the data type to be displayed

All systems (Daily): You can display the total electric power on a daily basis on a graph.


All systems (Monthly): You can display the total electric power on a monthly basis on a graph.

Select System (Daily): You can select the watt hour meter to sum and display the daily electric power on a graph.

Select System (Monthly): You can select the watt hour meter to sum and display the monthly electric power on a graph.




4 To select [Select System(Daily)] or [Select System(Monthly)], set the check box of the watt hour meter to sum to and tap [4-(1)]



An electric power graph is displayed.

NOTE


Tap to change the summary period to display. You can also tap the displayed date to display the calendar and change the summary period.



[Functions] Menu Settings


On the [Functions] menu, demand control of outdoor units and summation of data for power allocation can be performed.

How to display the [Functions] menu



1 Tap [1-(1)] appears.

2 Tap [2-(1)] [3-(1)] appears.



3 Tap the item you want to set with [3-(1)]
The settings screen of the selected item appears on the right.

For details on the setting contents of each item, refer to the following.

- Release power peak cut (P.59)
- Power peak cut schedule (P.60)
- Operation mode restriction (P.62)
- Automatic Meter-Reading (P.77)
- Manual Meter-Reading (P.78)
- System reboot (P.62)
- Scheduler Operation (P.63)
- Output to USB memory (P.63)

Release demand control of outdoor unit (Release power peak cut)



1 Tap [1-(2)] with [1-(1)]

2 Tap [2-(1)]
Outdoor demand set for all outdoor units is released.

NOTE


- Outdoor demand can be set by the "Power peak cut schedule". (P.60)
Outdoor demand may function with digital input set locally. In this case it can also be released.
- When you release the Power peak cut, the setting value of [Power peak cut] on the option screen changes to the release state. (P.46)

Set demand control schedule of outdoor unit (Power peak cut schedule)

The demand function of the outdoor unit can be managed with the schedule to 90 to 0% according to the peak time zone.

Setting example:


When "80%" at midnight on Monday, "90%" at midnight on Saturday, and "Release" at midnight on Sunday is set:



NOTE

- Cannot be set when the Outdoor Demand Schedule is disabled. Please enable the Outdoor Demand Schedule. (P.63)
- Demand levels that can be set are "Release", "90%", "80%", "70%", "60%" and "0%".
- Up to 10 schedules can be created.

Add/change Power peak cut schedule




1 Tap [1-(2)] with [1-(1)] (P.59)

2 Tap + to register new
To change, tap > of the schedule you want to change

NOTE


When the demand function is functioning at the current time, appears.




3 Tap [3-(1)] and set the check box of the outdoor unit for setting the Power peak cut schedule to

NOTE


The schedule number () will be displayed on outdoor units that have already been scheduled. Cannot be selected.




4 Tap the day of the week tab to start the schedule, then tap +
To change an already registered schedule, tap > on the corresponding schedule



5 Tap or flick to set the start time and tap [5-(1)]




6 Select the outdoor demand level and tap [6-(1)] to add a demand schedule



7 To add a schedule such as change/release of demand level, repeat steps 4 to 6


NOTE

- The outdoor demand initiated by the schedule is released in the following cases.
 - When demand release is set in the schedule
 - When demand control of the outdoor unit has been released (P.59)
- Demand control continues even across days.
 Example: When the demand rate is set to 0% on Monday at 13:00 and release is set at 6:00 on Tuesday
 → The demand rate is set to 0% from Monday at 13:00 to Tuesday at 6:00 and demand release occurs at 6:00 on Tuesday




8 Tap [8-(1)] and set the check box of the demand setting you want to delete to , then tap "delete"

Delete an Power peak cut schedule



1 Tap [1-(2)] with [1-(1)] (P.59)

2 Tap




3 Set the check box of the schedule you want to delete to , then tap [3-(1)]

The selected schedule will be deleted.

NOTE

Also, when deleting a registered time, tap and operate similarly.



Restrict operation mode (Operation mode restriction)

When using an outdoor unit that cannot operate cooling and heating at the same time, you can restrict its operation mode so that it can only be set for either cooling or heating.

1 Tap [Operation mode restriction] in the [Functions] menu (P.59)

2 Select the operation mode and tap [OK]

NOTE

- Settings are reflected in all outdoor units.
- Even with restriction, the operation mode of the [CONTROL] tab can be selected. When a restricted operation mode is selected, the Thermo OFF state is set.

Restart the Unit (System reboot)

You can restart the Unit if its operation becomes unstable.
The schedule is not executed during restart.

1 Tap [System reboot] in the [Functions] menu (P.59)

2 Tap [OK]

Set the operating schedule or the power peak cut schedule (Scheduler Operation)

You can disable registered Operation Schedules and Power peak cut schedules so that they do not operate.

- 1 Tap [Scheduler Operation] in the [Functions] menu (P.59)
- 2 Set the check box to if you do not want to operate each schedule, or set the check box to to operate them, then tap [OK]

Output data to a USB memory stick (Output to USB memory)

You can output monthly report/daily report files for power allocation, alarm files, or setting files to a USB memory stick.

- 1 Connect the USB memory stick to the slot in the Unit
- 2 Tap [Output to USB memory] in the [Functions] menu (P.59)
- 3 Tap [OK]


NOTE

If the USB memory stick is not connected, [OK] will not be enabled.


[Initial setting] Menu Settings

On the [Initial setting] menu, you can change the Unit screen display and the settings for remote operation, etc.

How to display the [Initial setting] menu



- 1 Tap [1-(1)] appears.
- 2 Scroll through the menu list and tap [2-(1)] [3-(1)] appears.
- 3 Tap the item you want to set with [3-(1)]
The settings screen of the selected item appears on the right.




For details on the setting contents of each item, refer to the following.

- Display Settings (P.64)
- Clock and calendar setting (P.64)
- Icon settings (P.65)
- Theme Settings (P.65)
- User Account Setting (P.66)
- Operation lock Setting (P.68)
- IP Address Setting (P.69)
- Alarm email address setting (P.70)
- Indoor unit area setting (P.71)
- Indoor unit name setting (P.72)
- Area name setting (P.72)
- Backlight setting (P.73)

Set the screen display (Display)

You can change the display settings of the screen, such as language and date display format.




- 1 Tap [1-(2)] with [1-(1)] (P.63)
- 2 Tap the item you want to change

- Language: You can change the display language of the screen.
- Date format: You can change the format of the date displayed in the upper right of the screen.
- First day of the week: You can change the first day of the week displayed on the calendar or schedule to Sunday or Monday.
- Temperature setting step: You can change the temperature setting step to 0.5°C or 1°C. However, it cannot be changed if the display unit is Fahrenheit.
- Temperature range (graph): You can change the temperature range displayed on the [GRAPH] tab.
- Decimal symbol: You can change the decimal symbol displayed on the screen between [. (dot)] and [, (comma)].

- 3 Select the value you want to change, then tap [3-(1)]


Set the current date and time (Clock and calendar)

You can change the date and time displayed in the upper right of the screen.




- 1 Tap [1-(2)] with [1-(1)] (P.63)
- 2 Tap the item you want to change
The background of the selected item changes to white.
- 3 Tap the numeric keypad to enter a number
- 4 Tap [4-(1)]

• NOTE

You can set daylight saving time with [Daylight-saving (Summertime)]. When set to [(1)], the time moves one hour forward, and when set to [(2)], it moves one hour back. While daylight saving time is set,  appears in the upper right corner of the screen.

Set icons of devices other than air conditioners (Icon)

You can display icons of each device on the [CONTROL] tab of devices other than air conditioners such as ventilation fan or lighting.



- 1** Tap [1-(2)] with [1-(1)] (P.63)
- 2** Tap the device you want to set with [2-(1)]
- 3** Tap the icon you want to set in the icon list
The selected icon is displayed in [2-(1)].
- 4** Tap [4-(1)]


NOTE

- To delete a set icon, select the device with [2-(1)] and then tap the space at the top left of the icon list.
- The following icons can be set:

	Ventilation fan/Circulator		Room air conditioner		Curtain		Alarm		Humidifier/Dehumidifier		Lighting
	Cubicle		Water storage tank		General switch		Security		Pump		Camera

Set the screen theme (Theme)

You can set the theme of the home screen and the details/control screen.



- 1** Tap [1-(2)] with [1-(1)] (P.63)
- 2** Tap the drop-down menu and select a theme
The selected theme appears in the preview. Operate the switch or tap the power supply or operation mode button to check the display after the change.
- 3** Tap [3-(1)]

Set an account for remote operation (User Account)


You can set a user account to operate the Unit remotely.

* Remote operation can be used when the Unit is connected via LAN to a PC on which the Remote Control Software is installed.

NOTE

- 128 users can be registered.
- Up to 16 users can log in at the same time.
- At least one user must be registered.

Add/change user account



- 1 Tap [1-(2)] with [1-(1)] (P.63)
- 2 To change, tap the row you want to change in the list

NOTE

The following users are registered in advance. You can also change/delete users.


Name: TCC
 Password: TCC
 Level: Administrators

- 3 Tap [3-(1)] or [3-(2)]

In the following procedure, the screen in the case of addition is used to explain.

- 4 Set Name (only when adding) and password

Tap the entry field to display the keyboard. After entering the characters, tap [4-(1)].



NOTE

- Tap [Shift] to toggle between upper case letters and lower case letters, and numbers and symbols.
- Tap to delete one character.

5 Set level

Administrators : All functions can be used.

Power Users : The following functions cannot be used.


- Confirm/change the operation schedule
- [Menu] > Functions
- [Menu] > Initial setting

Guests : Only the operation status can be confirmed. The settings cannot be changed.

NOTE


For details on the functions that can be used for each level, see "List by Lock Level/Level" (P.84).

6 Tap [6-(1)]



7 Tap [7-(1)]

Delete a user account




1 Tap [1-(2)] with [1-(1)] (P.63)

2 Tap the row you want to delete

3 Tap [3-(1)]

It will be deleted from the list.




4 Tap [4-(1)]

Deletion is confirmed.

Set the operation lock level (Operation lock)


1 Tap [1-(2)] with [1-(1)] (P.63)



2 Enter the password and tap [2-(1)]

NOTE


The factory default setting password is "1048".



3 Select the protection level during lock

NOTE


You can change the password that sets the operation lock. Tap [3-(1)] to display the change password input screen. Enter the changed password, tap [OK], re-enter it on the re-entry screen, then tap [OK]. 4-digit passwords can be set.



3

4 Tap [4-(1)]

Set the IP address of the Touch Screen Controller (IP Address)



- 1** Tap [1-(2)] with [1-(1)] (P.63)
- 2** Tap the value you want to change
The background of the selected item changes to white.
- 3** Tap the numeric keypad to enter a number
- 4** If there are other values you want to change, repeat steps 2 and 3
- 5** Tap [5-(1)]
The IP address is reset.

NOTE

- The initial setting is as follows:
IP address: 192.168.2.80
Subnet mask: 255.255.255.0
Default gateway: 0.0.0.0
- To return a changed value to the specified value, tap [(1)]. Tap [OK] on the confirmation screen to reset the IP address.




- 6** Tap [6-(1)]
The Unit restarts.

Set alarm email destination (Alarm email address)


You can set the email address to send email to when an alarm occurs.

NOTE

Up to five email addresses can be set.




- 1 Tap [1-(2)] with [1-(1)] (P.63)
- 2 Tap the address field to register



- 3 Enter the email address on the keyboard, then tap [3-(1)]

NOTE

- Tap [Shift] to toggle between upper case letters and lower case letters, and numbers and symbols.
- Tap  to delete one character.


- 4 Tap [OK]

NOTE

To test-send to the registered email address, tap [Test transmission], which displays after you tap [OK].

Change the area set for an indoor unit (Indoor unit area setting)

In [Indoor unit area setting], you can move the indoor unit A in area X to area Y.




NOTE

- [1] All areas. The area numbers, such as area 1 and area 2, are allocated automatically in the upper section of the home screen.
- [2] Each indoor unit in the area.

The procedure below is used as an example to explain how to move the indoor unit (AC001) set in area 1 to area 2.



1 Tap [1-(2)] in [1-(1)] (P.63)

2 Tap [2-(1)]




3 Tap [3-(1)]


Set the check box of the indoor unit (AC001) you want to move to area 2 to , and then tap [3-(2)], [3-(3)], and [3-(4)].




The indoor unit (AC001) is moved to area 2.



Set the name of an indoor unit (Indoor unit name setting)




- 1** Tap [1-(2)] in [1-(1)] (P.63)
- 2** Tap the name you want to change in the list
A keyboard is displayed. Enter the name and then tap [2-(1)].




- **NOTE**
- Tap [Shift] to toggle between upper case letters and lower case letters, and numbers and symbols.
- Tap to delete one character.

- 3** Tap [3-(1)]

Set the area name (Area name setting)



- 1** Tap [1-(2)] in [1-(1)] (P.63)
- 2** Tap the name you want to change in the list
A keyboard is displayed. Enter the name and then tap [2-(1)].




- **NOTE**
- Tap [Shift] to toggle between upper case letters and lower case letters, and numbers and symbols.
- Tap to delete one character.

- 3** Tap [3-(1)]

Set the screen brightness (Backlight)

You can set the brightness of the screen and the duration after the end of the operation. (30, 60, 360, or 720 minutes later)



1 Tap [1-(2)] with [1-(1)] (P.63)

2 Select the brightness and tap [2-(1)]

9 Remote monitoring using a PC

You can monitor and control the Unit by accessing it from a PC. This section explains the system diagram and the operating environment. For settings, etc., see "Settings for Remote Monitoring with a PC" (P.21).

NOTE

Some functions cannot be used from a PC. For details, please see "List by Lock Level/Level" (P.84).


Log in to Remote Control Software

NOTE

Up to 16 users can log in at the same time.




1 Double-click "AMTC_UI_****" on the desktop



2 Enter [User ID] [password], then click [2-(1)]

User ID/password:


Use the user account set up in step **1** of "Unit settings" (P.22).




The Remote Control Software home screen is displayed.


Log out from Remote Control Software

1 Click






2 Click [2-(1)]




3 Click [3-(1)]
You are logged out from the Remote Control Software.


Exit Remote Control Software



1 Tap [1-(1)]



2 Tap [2-(1)]



3 Tap [3-(1)]
Exit the Remote Control Software.

10 Power allocation

Electric Power Allocation System that can be Used with this Unit

In normal houses, a contract is made with the electric power company for each house, but in buildings such as offices and shops, a contract is made between the building owner and the electric power company, and the building owner pays the total electricity bill. Therefore, in some cases the building owner allocates the electricity fee that they paid in bulk to each tenant and invoices for a fee.

With this Unit, you can record the operating time of the air conditioner(s) and the ON/OFF unit, and distribute the electric power of each device based on that data.

In addition, by using the Report Creation Software, you can easily summarize the operation results in a report format and calculate the billing amount.


Example report

番号	フロア	テナント	エリア	ユニット	運転時間[h]	電力量[kWh]	課金金額[円]	税込金額[円]	時間内運転時間[h]
1	FLOOR-1	TENANT-A	** 名称なし **	unit1-1-1	200.0	774.72	14395	15115	133.3
2	FLOOR-1	TENANT-A	** 名称なし **	unit1-1-2	133.3	1622.70	28648	30079	65.7
3	FLOOR-1	TENANT-A	area2	unit1-1-3	200.0	1278.45	23782	24971	133.3
4	** 除外 **	TENANT-B	** 除外 **	** 除外 **	133.3	** 除外 **	** 除外 **	** 除外 **	65.7
5	FLOOR-1	TENANT-B	area3	unit1-2-2	133.3	1309.01	21808	22888	65.7
6	FLOOR-1	TENANT-B	area3	unit1-2-3	200.0	1545.07	32795	34372	165.7
7	FLOOR-1	TENANT-C	area1	unit1-1-1	133.3	850.37	14300	15015	65.7
8	FLOOR-1	TENANT-C	area1	unit1-1-2	200.0	1287.55	27278	28843	165.7
合計					1333.3	8675.9	162946.4	171093.3	865.7

CAUTION

This system calculates the allocation of the power by load ratio estimated for each air conditioner. The result may differ from the actual power consumed. In addition, the result is not calculated based on the Measurement Act and cannot be used officially.

System diagram



Power Allocation System

In order to perform power allocation, it is necessary to sum the data for power allocation. Summing may be done by automatic meter-reading or manual meter-reading.

Set the summation date of the power allocation data (Automatic Meter-Reading)

You can set the date for automatic meter-reading of the power allocation data. Automatic meter-reading is carried out on the set date, and data from the previous meter-reading date to the set date is output as a monthly report file.

It can be set according to the convenience of the building owner or tenant. For example, it is possible to sum over a period as follows.

- Sum to the end of the month each month (Set the automatic meter-reading day to the end of the month and sum from the 1st to the end of the month)
- Sum to the 15th of every month (Set the 15th of the month as the automatic meter-reading day and sum from the 16th of the previous month to the 15th of the current month)
- Sum by dividing each month into two (Set the 15th of the month and the end of the month as the automatic meter-reading days and sum twice, from the 1st to the 15th and from the 16th to the end of the month)
- Sum two months (Set the end of every other month as the meter-reading day and sum from the 1st of the preceding month to the end of the current month)

By setting automatic meter-reading, you can use the system for monthly electricity billing.



1 Tap [1-(2)] with [1-(1)] (P.59)

2 Select the day you want to meter-read on the calendar and tap [2-(1)]


• **NOTE**

- You can set the schedule for one year from the current month.
- You can set up to two days for every month. Months without meter-reading can also be set.
- Tap the selected day again to release the setting.
- The meter-reading result file (monthly report/daily report file) can be output to a USB memory stick. (P.63)


◆ **To batch set meter-reading days**

1 Tap []

2 Tap a number, enter the date, then tap [2-(1)]




3 Tap [3-(1)]



Sum data for power allocation as necessary (Manual Meter-Reading)

You can manually meter-read the data for power allocation from the previous meter-reading day until the current day. Manual meter-reading is convenient if you need to sum data for power allocation before the automatic meter-reading day, such as when a tenant leaves.



1 Tap [1-(2)] with [1-(1)] (P.59)

2 Tap [2-(1)]

The meter-reading result file is added to [2-(2)].

NOTE

The meter-reading result file (monthly report/daily report file) can be output to a USB memory stick. (P.63)

1-(2)
The file names of automatic or manual meter-readings and meter-reading periods are displayed in a list.

2-(2)
The period for which manual meter-reading is carried out (the previous meter-reading day to the current day) is displayed.

How to use the power allocation system

1 Download the data for power allocation

Save the data for power allocation to the PC using one of the following procedures.

- 1) Download by LAN connection
Download the data using the Report Creation Software.
- 2) Copy the data to a USB memory stick
Output the data to the USB memory stick using the Unit's [Output to USB memory] and import the data using the Report Creation Software.

2 Create monthly reports and daily reports

Create a monthly report or daily report from [Run] - [Download & create monthly/daily report] in the Report Creation Software.

3 Click the month or day you want to display

4 Click the [View report] button

NOTE

For details, refer to the instruction manual of the Report Creation Software.

11 Troubleshooting

Phenomenon	Question	Confirmation items
The LCD does not display.	Is the power turned on?	Check that the power is not turned off by the breaker or the like. There is a green LED at the lower rear of the main unit and a green LED on the AC adapter that indicate that power is being supplied.
		Check that the wiring of the power outlet and AC adapter is not disconnected. There is a green LED at the lower rear of the main unit and a green LED on the AC adapter that indicate that power is being supplied.
	Has the backlight gone out?	The LCD turns off when there is no operation for a certain period of time. Touch the touch panel to turn on. The brightness and display time can be changed using [Backlight].
	Is the backlight brightness dark?	Adjust the brightness using [Backlight].
The operated air conditioner does not run.	Does the operated air conditioner match the actual air conditioner?	Operate another air conditioner and check if the actual air conditioner operates.
	Is an alarm occurring?	The air conditioner will not operate when an alarm is occurring. Turn off the alarm.
	Are you operating with the local remote control?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Is the air conditioner stopped due to the schedule setting of the local remote control or the like?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control schedule, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Are you operating with the PC app "Remote Control Software"?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the PC app "Remote Control Software", it will stop. The latter operation of this Unit or the "Remote Control Software" overrides the former.
I want to turn off the power.	There is no power switch.	Please remove the AC adapter or turn off the circuit breaker.
I want to reboot.	Reboot from the menu.	Select [Menu] - [Functions] - [System reboot].
The air conditioner settings change arbitrarily.	Are you operating with the local remote control?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Is the air conditioner stopped due to the schedule setting of the local remote control or the like?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the local remote control schedule, it will stop. The latter operation of this Unit or the local remote control overrides the former.
	Have you applied settings such as stop using an external input signal?	When stop, etc. is set by an external input signal using the external interlocking function, the air conditioner stops automatically when a signal is input.
	Are you operating with the PC app "Remote Control Software"?	Even if the air conditioner is run with this Unit, if it is stopped afterwards with the PC app "Remote Control Software", it will stop. The latter operation of this Unit or the "Remote Control Software" overrides the former.
The schedule does not work.	Is the schedule disabled?	Please confirm the Scheduler Operation settings.
	Does the scheduled air conditioner match the actual air conditioner?	Operate another air conditioner and check if the actual air conditioner operates.
	Is a Particular Timer setting set?	If a day is set in both the Week Schedule and a Particular Timer setting, the Particular Timer setting will apply for that day.

Phenomenon	Question	Confirmation items
The air conditioner doesn't cool. The air conditioner doesn't heat.	Is demand control turned on?	Demand control suppresses the capability of the outdoor unit in order to reduce power consumption. Therefore, it may take time to reach the set temperature.
	Is the forced thermo OFF control turned on?	Forced thermo OFF is a control to stop the operation of the outdoor unit. Therefore, the indoor unit acts as a fan.
	Is the power saving control turned on?	Power saving suppresses the capability of the outdoor unit. Therefore, it may take time to reach the set temperature.
The LCD does not turn off.	Is an alarm occurring?	The LCD will still be on when an alarm is occurring. Turn off the alarm.
Sometimes the LCD becomes black for a moment.	The LCD's antistatic control is working.	Temporarily stop the LCD periodically to prevent LCD burn-in. Not a malfunction.
The setting displayed on the local remote control does not match the setting displayed on this Unit.	Does the operated air conditioner match the actual air conditioner?	Operate another air conditioner and check if the actual air conditioner operates.
I would like to frequently change detailed settings such as set temp. and setting mode for all air conditioners.	Only "ON" and "OFF" can operate all air conditioners at once.	You can set the set temp., setting mode, etc. for each air conditioner group by group. Please group the air conditioners.
When local remote control operation is prohibited, if there is a power failure, the local remote control prohibited status will be cancelled when the power returns.	-	Ask service personnel if you want to continue the local remote control prohibited status after returning from a power failure.
FILTER information can be reset even when the FILTER sign is not displayed.	The FILTER sign lights up depending on the accumulated operation time.	As the operation time accumulates, the FILTER sign lights up when the preset operation time is reached. The FILTER sign information can be reset to clear the accumulated time for cases such as when FILTER cleaning is carried out before the FILTER sign turns on.
I want to check the software version.	Reboot from the menu.	The version is displayed under [Menu] - [Information].
Reboot from time to time.	Please check for noise and the power supply status.	The main unit may restart if noise in the surroundings or an unstable power supply cause the operation of the software to be unstable. Please check the surrounding environment.
I cannot start the Remote Control Software.	Is "Error 1001" displayed?	Please download .Net Framework 4.6.2 from the download website of this software and install it.
	Is the LAN cable connected?	This software will not start unless the PC and the LAN of this Unit are connected. Check the LAN cable connection and network settings.
	Is the IP address of the access destination set to the IP address of the controller main unit?	The IP address (or server name) to be entered during installation is the IP address of the controller main unit. It is not the IP address of the PC. If it is incorrect, please do the following and then reinstall. 1. Uninstall the application 2. Delete the install destination directory 3. Delete the desktop and start menu shortcuts
	Is the PC on which the software was installed Windows 8.1 or 10?	Windows 8.1 and 10 are supported. The software may not operate correctly when installed on a PC with a different OS.
I cannot log in to the Remote Control Software.	Have you logged in as the same user from another PC?	Each user can log in from only one PC at the same time.
	Is the Windows display style set to classic style?	Please select a display style other than classic style. You can change the display style from [Start] - [Control Panel] - [Appearance and Personalization] - [Change the theme]. This software supports Windows 8.1 and 10.

Phenomenon	Question	Confirmation items
I cannot log in to Remote Control Software from another PC after the LAN is disconnected.	Have you logged in with the same user ID?	You must log in again from a PC with the LAN disconnected and log out normally.
	Have you accessed the software from more than 8 PCs?	Up to 8 PCs can be accessed at the same time. The software may not operate correctly if you connect to more than 9 PCs.
	Did you assign the PC's IP address using a DHCP server?	This Unit judges whether it is accessed from the same PC using the IP address. If the PC address is changed partway through by the DHCP server, you may not be able to log in again after LAN disconnection. Please set the PC that accesses this Unit to a fixed IP or reboot the Unit and erase the login information.
The language does not switch with the Remote Control Software.	Does the login user for the Windows being used have write permission for the Remote Control Software storage location?	Please allow write permission below the folder where Remote Control Software is saved (initial setting: C:\Program Files\TOSHIBA Carrier Corporation). Right-click on the TOSHIBA Carrier Corporation folder, select the [Properties] - [Security] Name, click the "Edit" button and check [Allow] for [Full control] under different settings.
The schedule setting changes have not been reflected.	Are you trying to change the schedule settings on both the Remote Control Software and the main unit?	To change the schedule settings, please set only one of either the main unit or the Remote Control Software.
I would like to use the software with other centralized controllers.	Centralized controllers that can be used together within the same TCC-LINK.	It is possible to use up to 8 units together with all centralized controllers including this Unit. Ask service personnel to use them in combination.
I want to use multiple units in combination.	Number of units that can be used in combination in the same TCC-LINK.	It is possible to use up to 8 units together with all centralized controllers including this Unit. Ask service personnel to use them in combination.
The LCD sometimes turns black for a moment.	The LCD's antistatic control is working.	This is not a malfunction. The LCD may turn black temporarily to remove static electricity.
The multi outdoor unit's option board control does not work.	Do you want to use the multi outdoor unit's option board?	When the centralized controller is connected, the functions of the outdoor unit's option board become ineffective. Only one of the centralized controller and the outdoor unit's option board can be used.
The Unit does turn ON/OFF even though the operation interlock signal/stop interlock signal is input.	Has the interlock signal been input from the time of activation?	Since the interlock signal confirms the state by detecting the rising edge and falling edge, if the interlock signal is input from the time of activation, interlock control will not be performed. Please set so that the interlock signal turns OFF at the time of activation.

12 Useful information

The following cases are not faults with the Unit.

Problem	Cause
When an air conditioner is stopped, its operation status is displayed on the LCD display part of the Touch Screen Controller.	This is because even when an air conditioner is stopped, you can set its operation from the Touch Screen Controller.
The display does not switch even if you operate the Touch Screen Controller.	<ul style="list-style-type: none"> • The function is not provided by the air conditioner. • There may be an error in the operation method. Please check the operation explanation of the function. • This is because switching of HEAT and COOL in the operation mode is prohibited.
It is not set even when operating the Touch Screen Controller.	

Please check the following before requesting service.

Problem	Cause	Solution
The air conditioner does not operate even when I press the Run/Stop switch on the Touch Screen Controller.	Has a power outage occurred?	If the LCD of the Touch Screen Controller does not display, press the ON/OFF button of the Touch Screen Controller again after energizing the controller.
The check lamp of the Touch Screen Controller lights up.	Is the air conditioner protection device operating?	Please see the air conditioner operation manual and check the operation.
On the LCD display part of the Touch Screen Controller \triangle (Abnormality) and the check code C06 is displayed.	Is a power outage affecting the air conditioner?	After restoring power to the air conditioner, the display will disappear after waiting a few minutes.

If you have investigated the above and there is still an abnormality, please contact the dealer from whom you purchased the Unit with the part number and problem.

Under no circumstances conduct repairs by yourself. Doing so is dangerous.

Moreover, if the LCD display part of the Touch Screen Controller displays \triangle (Abnormality) and a check code, please also inform the dealer of these items.

13 Appendix

Specifications

Detailed specifications

Power supply	220-240 V AC 50/60 Hz
Operating temperature/humidity range	0°C to 40°C, 10% to 90% RH (no dew condensation)
Dimensions (mm)	H136×W205×D10(+80) (Embedded dimensions shown in parenthesis)
Mass	1.34 kg (Touch Screen Controller) 0.45 kg (power adapter)
LCD	Type 7 TFT liquid crystal, 800×480, 167,000 colours (Luminance 800 cd/m ² , contrast ratio 600:1)
Touch Screen	Projection-capacitive type
Communication ports	· RS-485 port ×1 (for connecting four digital I/O interfaces and four watt hour meter interfaces) · LAN port ×1 (for connecting PC)
USB port	USB memory stick connection port ×2
External contact input	8 inputs
External contact output	4 inputs
Included PC software (Requires a separate PC (*1))	· Remote Control Software · Report Creation Software · Section Changeover Software · Data Analyzer

*1 Conditions for PC connection (operating environment)

OS: Windows 8.1 or Windows 10

LAN port: 10BASE-T or 100BASE-TX wired LAN port

Other: mouse/keyboard, printer (if printing is required)

Function list

Key Features		
Control	ON/OFF	
	Setting mode	
	Set temp.	
	Fan speed settings	
	Swing ON	
	Local remote controller operation lock/unlock	
	Ventilation → ON/OFF	
	Ventilation → Mode	
	Ventilation → Fan speed	
	Soft Cooling	
	Energy saving ratio [%]	
	Eco Temperature Shift	
	Set temp. range limit	
	Filter Sign Reset	
	Monitoring	ON/OFF
Setting mode		
Set temp.		
Fan speed settings		
Swing ON		
Local remote controller operation lock/unlock		
Ventilation → ON/OFF		
Ventilation → Mode		
Ventilation → Fan speed		
Soft Cooling		
Energy saving ratio [%]		
Eco Temperature Shift		
Set temp. range limit		
Outdoor temp.		
Power Level		
Return Back		
Power peak cut		
FILTER Sign		
Schedule	Setting unit (Per unit)	
	Setting unit: Week Schedule (per day of the week)	
	Setting unit: Particular Timer setting (per date)	
	Setting time (00:00 to 23:59)	
	Setting content	ON/OFF
		Setting mode
		Set temp.
		Local remote controller operation lock/unlock
		Return Back
		Energy saving ratio [%]
Ventilation operation setting		
Vent. Mode		
Maximum number of schedules per day 64		

Key Features			
External input	Inputs	Main unit	8 inputs
		DIO interface	8 inputs x 4 units
	Functions	Power pulse measurement	
		Demand Interlocking	
		Fire Alarm Interlocking	
		Security Interlocking	
		Stop Interlocking	
		Operation Interlocking	
		For ON/OFF indication	
		For alarm indication	
External output	Outputs	Main unit	4 outputs
		DIO interface	4 outputs x 4 units
	Functions	Alarm Output Interlocking	
		Operation Output Interlocking	
		Controller Error Output Interlocking	
		For ON/OFF control	

Glossary

◆ **Power peak cut**

The maximum demand power, which is the power value used to calculate the electricity fee from the electric power company.

The monthly electricity fee is composed of the "basic fee" and the "power fee". The "power fee" is calculated according to the usage of electricity in the month, but the "basic fee" is determined according to the month when the Power peak cut was the highest in the past year. Since the time when Power peak cut increases, such as summer, is limited, keeping Power peak cut to the average is a key point to reduce the basic fee.

◆ **During power peak cut control**

Control to cut the peak of electric power usage.

◆ **Flap**

A part that changes the air direction at the outlet. It is also called a louvre.

◆ **ON/OFF unit**

Indicates devices that cannot control or monitor set temperature or setting mode among the managed devices. Main equipment includes lighting settings, air to air heat exchangers, ventilation fans, etc.

◆ **Thermo OFF**

An energy saving function whereby when the temperature of a room reaches the set temperature, the outdoor unit compressor stops to switch from cooling/heating to fan operation.

Although the indoor unit (air conditioner) is in operation, the outdoor unit repeatedly turns ON/OFF depending on the room temperature.

List by Lock Level/Level

Refer to the following table for the functional differences depending on the operation of the main Unit and remote operation, the level of the operation lock of the main Unit and the level of the user account.

(○: Full functional operation △: Partially restricted -: Cannot be used)

Item	Unit Operation			Remote Operation			
	Operation Lock None	Operation Lock - Level 1	Operation Lock - Level 2	Administrators	Power Users	Guests	
Home screen	○	○	△	○	○	△	
Group screen	[CONTROL] tab	○	○	-	○	○	-
	[SCHEDULE] tab	○	-	-	○	-	-
	[GRAPH] tab	○	○	-	○	○	-
Individual control screen	[CONTROL] tab	○	○	-	○	○	-
	[SCHEDULE] tab	○	-	-	○	-	-
	[GRAPH] tab	○	○	-	○	○	-
SCHEDULE	Week Schedule	○	-	-	○	-	-
	Particular Timer setting	○	-	-	○	-	-
Batch ON/OFF screen	○	○	△	○	○	△	
Alarm history screen	○	○	△	○	○	△	

Item		Unit Operation			Remote Operation			
		Operation Lock None	Operation Lock - Level 1	Operation Lock - Level 2	Administrators	Power Users	Guests	
Menu	Operation lock screen	○	○	○	○	○	○	
	Alarm History	○	○	○	○	○	○	
	Electric power	○	○	○	○	○	○	
	Functions	Release power peak cut	○	–	–	○	–	–
		Power peak cut schedule	○	–	–	○	–	–
		Operation mode restriction	○	–	–	○	–	–
		Automatic Meter-Reading	○	–	–	○	–	–
		Manual Meter-Reading	○	–	–	○	–	–
		System initialize	○	–	–	○	–	–
		Scheduler Operation	○	–	–	○	–	–
		Output to USB Memory	○	–	–	–	–	–
	Settings	Display Settings	○	–	–	○	–	–
		Clock and calendar setting	○	–	–	○	–	–
		Icon settings	○	–	–	○	–	–
		Theme Settings	○	–	–	○	–	–
		User Account Setting	○	–	–	–	–	–
		Operation Lock Setting	○	–	–	○	–	–
		IP Address Setting	○	–	–	–	–	–
		Alarm email address setting	○	–	–	–	–	–
		Indoor unit area setting	○	–	–	–	–	–
		Indoor unit name setting	○	–	–	–	–	–
		Area name setting	○	–	–	–	–	–
	Backlight setting	○	–	–	–	–	–	
Support screen	○	○	○	○	○	○		
Logout	–	–	–	○	○	○		

14 Warranty and after-sales service

About the Warranty


- The warranty period is one year from date of purchase.

About After-Sales Service


- Please check "11. Troubleshooting" (P.79) before requesting a repair. If this does not solve the problem, immediately shut off the power supply and contact us.
- Please inform us of the following when requesting a repair.
 - Customer name
 - Address, phone number
 - Product model name and serial number
 - Installation date
 - Failure status (as much detail as possible)

Contact for after-sales service (Information)

For after-sales service, please contact here.



- 1 Tap , then tap [1-(1)]
The contact information is displayed.



OSS License

This product contains licensed software or software whose copyright is owned by a third party according to the following.

OpenSSH

This file is part of the OpenSSH software.

The licences which components of this software fall under are as follows. First, we will summarize and say that all components are under a BSD licence, or a licence more free than that.

OpenSSH contains no GPL code.

1)

- * Copyright (c) 1995 Tatu Ylonen <ylo@cs.hut.fi>, Espoo, Finland
- * All rights reserved
- *
- * As far as I am concerned, the code I have written for this software
- * can be used freely for any purpose. Any derived versions of this
- * software must be clearly marked as such, and if the derived work is
- * incompatible with the protocol description in the RFC file, it must be
- * called by a name other than "ssh" or "Secure Shell".

[Tatu continues]

- * However, I am not implying to give any licenses to any patents or
- * copyrights held by third parties, and the software includes parts that
- * are not under my direct control. As far as I know, all included
- * source code is used in accordance with the relevant license agreements
- * and can be used freely for any purpose (the GNU license being the most
- * restrictive); see below for details.

[However, none of that term is relevant at this point in time. All of these restrictively licenced software components which he talks about have been removed from OpenSSH, i.e.,

- RSA is no longer included, found in the OpenSSL library
- IDEA is no longer included, its use is deprecated
- DES is now external, in the OpenSSL library
- GMP is no longer used, and instead we call BN code from OpenSSL
- Zlib is now external, in a library
- The make-ssh-known-hosts script is no longer included
- TSS has been removed
- MD5 is now external, in the OpenSSL library
- RC4 support has been replaced with ARC4 support from OpenSSL
- Blowfish is now external, in the OpenSSL library

[The licence continues]

Note that any information and cryptographic algorithms used in this software are publicly available on the Internet and at any major bookstore, scientific library, and patent office worldwide. More information can be found e.g. at "<http://www.cs.hut.fi/crypto>".

The legal status of this program is some combination of all these permissions and restrictions. Use only at your own responsibility. You will be responsible for any legal consequences yourself; I am not making any claims whether possessing or using this is legal or not in

your country, and I am not taking any responsibility on your behalf.

NO WARRANTY

BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

3)

ssh-keyscan was contributed by David Mazieres under a BSD-style license.

* Copyright 1995, 1996 by David Mazieres <dm@lcs.mit.edu>.

*

* Modification and redistribution in source and binary forms is permitted provided that due credit is given to the author and the OpenBSD project by leaving this copyright notice intact.

4)

The Rijndael implementation by Vincent Rijmen, Antoon Bosselaers and Paulo Barreto is in the public domain and distributed with the following license:

* @version 3.0 (December 2000)

*

* Optimised ANSI C code for the Rijndael cipher (now AES)

*

* @author Vincent Rijmen <vincent.rijmen@esat.kuleuven.ac.be>

* @author Antoon Bosselaers <antoon.bosselaers@esat.kuleuven.ac.be>

* @author Paulo Barreto <paulo.barreto@terra.com.br>

*

* This code is hereby placed in the public domain.

*

* THIS SOFTWARE IS PROVIDED BY THE AUTHORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE

* LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
* CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF
* SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR
* BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
* WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE
* OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE,
* EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

5)

One component of the ssh source code is under a 3-clause BSD license, held by the University of California, since we pulled these parts from original Berkeley code.

* Copyright (c) 1983, 1990, 1992, 1993, 1995
* The Regents of the University of California. All rights reserved.
*
* Redistribution and use in source and binary forms, with or without
* modification, are permitted provided that the following conditions
* are met:
* 1. Redistributions of source code must retain the above copyright
* notice, this list of conditions and the following disclaimer.
* 2. Redistributions in binary form must reproduce the above copyright
* notice, this list of conditions and the following disclaimer in the
* documentation and/or other materials provided with the distribution.
* 3. Neither the name of the University nor the names of its contributors
* may be used to endorse or promote products derived from this software
* without specific prior written permission.
*
* THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS'' AND
* ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
* ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE
* FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
* DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
* OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
* HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
* LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
* OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
* SUCH DAMAGE.

6)

Remaining components of the software are provided under a standard 2-term BSD licence with the following names as copyright holders:

Markus Friedl
Theo de Raadt
Niels Provos
Dug Song
Aaron Campbell
Damien Miller
Kevin Steves
Daniel Kouril
Wesley Griffin
Per Allansson

Nils Nordman
Simon Wilkinson

- * Redistribution and use in source and binary forms, with or without
- * modification, are permitted provided that the following conditions
- * are met:
- * 1. Redistributions of source code must retain the above copyright
- * notice, this list of conditions and the following disclaimer.
- * 2. Redistributions in binary form must reproduce the above copyright
- * notice, this list of conditions and the following disclaimer in the
- * documentation and/or other materials provided with the distribution.
- *
- * THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS" AND ANY EXPRESS OR
- * IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES
- * OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.
- * IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT,
- * INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT
- * NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE
- * DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY
- * THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT
- * (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF
- * THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

\$OpenBSD: LICENCE,v 1.20 2017/04/30 23:26:16 djm Exp \$

Toshiba Carrier Corporation

336 TADEHARA, FUJI-SHI, SHIZUOKA-KEN 416-8521 JAPAN